

2200CW Series

Digital Checkweighing Indicator

Technical Manual



Table of Contents

Introduction	1
Unpacking Your Scale.....	1
Specifications	2
Scale Controls and Operation	3
Scale Annunciators	3
Powering On.....	4
Basic Weighing Operation.....	4
ZERO.....	4
TARE.....	5
Keyboard TARE entry	5
Display TARE value	5
Clear TARE value.....	5
GROSS NET selection.....	5
UNITS	5
PRINT.....	5
OVER	5
UNDER.....	6
Battery Operation.....	7
Power Off	7
Low Battery Indication	7
Recharging Battery	7
Three Band Checkweighing.....	8
Three Band Checkweighing (9.1 [L.O. set to operation starting with 3]).....	8
Enter and Display of Checkweigh Limits (9.2 [L.E. default value 5[r).....	8
Weight Reference and Digital Entry of Checkweigh Limits (9.2 [L.E. set to 5[5).....	8
Weight Reference Entry of Checkweigh Limits (9.2 [L.E. set to P b).....	8
Five Band Checkweighing.....	9
Five Band Checkweighing (9.1 [L.O. set to operation starting with 5).....	9
Enter and Display of High and Low Limits (9.2 [L.E. default value 5[r).....	9
Weight Reference and Digital Entry of High and Low Limits (9.2 [L.E. set to 5[5).....	9
Weight Reference Entry of High and Low Limits (9.2 [L.E. set to P b).....	10
Zero Band Checkweighing.....	10
Zero Band Checkweighing (9.1 [L.O. set to operation starting with 0).....	10
Product ID	11
Recall PRODUCT ID from Memory.....	11
Barcode Scan Recall PRODUCT ID from Memory	11
Display Current PRODUCT ID.....	11
Create New PRODUCT ID	11
Delete PRODUCT ID from Memory.....	12
User ID	12
User ID login	12
Barcode Entry of User ID Values.....	12
User ID Logout	12
Product Fields.....	13

Display Product Fields.....	13
Product Field Entry	13
QC Weigh Operation.....	14
Entering QC Weigh Mode.....	14
Entering a User ID.....	14
Entering a Product ID.....	14
Checkweigh Operation.....	15
Time and Date	16
Setting Time and Date.....	16
Accumulator and Counter.....	17
Accumulator and Counter Operation	17
Display Accumulator and Counter Values.....	17
Clear Accumulator and Counter	17
Accumulator and Counter Data String Output to Printer or Data Collection	17
Installation Guide	18
Removing and Replacing the Rear Panel	18
Heartbeat LED.....	18
Load Cell Connection	19
Power Connection and Fuse.....	20
RS232 and Remote Switch Connection.....	20
Output Connections.....	23
Calibration Guide.....	24
Entering Calibration and Parameter Setup Mode	24
Exit Calibration and Parameter Setup Mode	24
Set Scale Capacity	24
Set Scale Count By	25
Calibration.....	25
Calibration Error Codes.....	25
Scale Calibration Error Troubleshooting.....	26
Scale Parameter Setup.....	27
Entering Calibration and Parameter Setup Mode	27
Exit Calibration and Parameter Setup Mode	27
Navigating Parameter Menu with Keypad.....	27
Navigating Parameter Menu with ZERO, UNITS, and PRINT.....	27
Parameter Groups	28
Legal for Trade Restrictions.....	28
Audit Counters.....	28
Software Part Number and Revision Level	28
Capacity and Calibration - 1 [A]	29
General Settings - 2 [nFg].....	33
Serial (RS232) Port 1 - 3 [5Er 1].....	36
Serial (RS232) Port 2 - 4 [5Er 2]	37
Wired Ethernet - 5 [Et h]	39
Wireless Ethernet - 6 [u u F]	41
Bluetooth - 7 [b t]	44
USB - 8 [U S b].....	45
Checkweigh and Output Operation - 9 [O P E r]	46
Exit - 99 [d o n]	48

Data Communications	49
Data String Formatting.....	50
Custom Data String Configuration.....	55
Remote Commands	58
Internal Relay Option	61
Internal Relay Setup:	61
Relay Specifications:	61
Step-up Relay Circuit.....	62
4-20mA Analog Output Option	63
Wired Ethernet Option	64
Wireless 802.11b/g Ethernet Option.....	65
Troubleshooting Wifi	66
Bluetooth Option.....	67
Bluetooth Pairing Instructions.....	68
Troubleshooting	72
Scale Messages	73
Default to Factory Settings.....	74
Scale Default Settings	74

Introduction

Thank you for purchasing a Doran Scales product. Please read this manual to ensure obtaining all the benefits that the indicator can provide. This manual is intended for revision 5.3 and greater scales. If required, Doran can upgrade the software in your scale to the current revision. Please contact the Doran Scales Technical Support Department at tech@doranscales.com for upgrade details.

Unpacking Your Scale

Before unpacking your Doran scale, please read the instructions in this section. Your new scale is a durable industrial product, but it is also a sensitive weighing instrument. Normal care should be taken when handling and using this product. Improper handling or abuse can damage the scale and result in costly repairs that will not be covered by the warranty. If you notice any shipping damage, notify the shipper immediately. Please observe the following precautions to insure years of trouble-free service from your new scale.

- DO NOT drop the scale
- DO NOT immerse the scale
- DO NOT drop objects on the platform
- DO NOT pick up the scale by the top of the weighing platform
- Carefully remove the scale from the shipping carton

Specifications

NTEP Certificate	Class III – 10,000d; Cert. #06-101
CWM Certificate	Class III – 10,000d; Cert. #AM-5617
Enclosure	304 Stainless Steel
Product Dimensions	10" W x 6.75" H x 3.5" D
Environmental Protection	IP69K
Legal for Trade Temperature Range	14 F to 104F (-10 C to +40 C)
Resolution Range	200d to 100,000d
Analog Signal Sensitivity	0.16 μ V/e minimum, 0.5 μ V/e typical
System Linearity	0.01% full scale
Analog Signal Range	-0.5mV/V to 5 mV/V with 4 and 6 wire input
Excitation Voltage	5 VDC
Number of Load Cells	Up to 8 350 Ohm
Scale Inputs	One
Calibration Range	Calibrate between 2% and 100% of capacity
Power Input	100 – 240VAC 50/60Hz
Battery Option	Internal Rechargeable Sealed Lead Acid Battery 6VDC, 60 hours of continuous use, 1000 recharge cycles
Display	0.8" high, 6 digit LED
Displayed Units	lb, kg, oz, g, lb:oz
Capacity Range	1 to 999,000 lb
Serial Interface	Two Bi-directional RS-232 ports standard
Communication Options	Ethernet Wi-Fi – 802.11b/g Bluetooth – 4.0, Class 3, SPP Protocol USB – 2.0, CDC Protocol 4-20 mA – Active current loop Audible Alarms Light Tower
Digital IO	Two remote switch inputs Eight outputs – 4.7 or 12 VDC configurable up to 800mA. current-sinking Darlington pair

Scale Controls and Operation



Fig. 1: Front Panel

Scale Annunciators

Unit of measure lb, oz, kg, g or lb:oz. The units annunciator to the right of the display will indicate the current unit of measure.

NET

Net weighing mode is indicated by the NET annunciator. The annunciator will illuminate when a net weight is displayed. When not illuminated, a gross weight is displayed.



Battery option status indicator. When the annunciator illuminates, the battery charge is low and the scale should be plugged in to recharge the battery. While the scale is charging, the battery annunciator will flash. When the charging is complete, the annunciator will turn off.



Center of zero. The annunciator will illuminate while the scale is displaying a zero weight.



Motion indicator. This symbol represents motion or instability of the weight. The annunciator will illuminate when motion is sensed on the platform. Changes in weight, vibration or air currents can cause the scale to go into motion.

Under illuminates to indicate weight is below the Under target and above the Low target or flashes if below the Low target.

Accept illuminates to indicate weight is at or above the Under target and at or below the Over target.

Over illuminates to indicate weight is above the Over target and below the High target or flashes if above the High target.

Powering On

Connect the cord to a compatible power source.

For indicators with battery option, press and hold ZERO.

Basic Weighing Operation

- 1) Remove all items from the scale platform
- 2) Press the ZERO button to zero the scale
- 3) The weight display now reads zero
- 4) Place an item on the scale platform and wait for the motion annunciator to turn off, indicating an accurate, stable weight

ZERO

ZERO is used to zero the scale. To zero the scale, press the ZERO button. The scale will not zero if the scale is in motion. The zero function will operate over the entire capacity of the scale.

If the scale is displaying a net weight, pressing ZERO will return the scale to gross mode and display a zero weight. The stored tare will remain in memory.

The scale is equipped with a Zero on Demand parameter which zeros the scale upon the next stable reading after ZERO is pressed.

TARE

Place the item you wish to tare on the scale platform and press TARE. The scale will display a net weight and the NET annunciator will illuminate.

Tare weights will remain in memory even if the indicator is turned off.

Keyboard TARE entry

Enter a weight and press TARE to save or press CLEAR to cancel tare entry. The scale will display a net weight and the NET annunciator will illuminate.

Display TARE value

To display the current tare value, press and hold TARE for three seconds. The display will briefly read $\pm \overline{0.00}$ then flash the tare weight in the currently selected units. To exit press CLEAR.

Clear TARE value

Enter 0 and press TARE. This will remove the tare weight from memory.

GROSS NET selection

Press the GROSS NET button to switch between the gross and net weighing mode. Switching to the net mode is possible only when a tare is entered. Net mode is indicated when the NET annunciator is illuminated.

UNITS

UNITS selects the unit of measure. Press UNITS to change the current unit. The units annunciator to the right of the display will indicate the current unit or measure: lb,oz, kg, g or lb:oz.

Each unit can be enabled or disabled in the scale parameter setup. Lb:oz is disabled by default. Lb:oz is not available for tolerance, checkweigh, or setpoint values and cannot be transmitted as data.

PRINT

PRINT transmits data to a printer or other external devices. When the data is transmitted, the leftmost display digit will momentarily display an "r" to confirm data transmission.

There are many parameters that customize the control of manual and automatic transmission of data. Data can be transmitted via standard RS232, Ethernet, WiFi, Bluetooth or USB options. Contact Doran Tech Support at tech@doranscales.com for support.

OVER

OVER allows entry of the upper checkweighing limits. It is also used to increment a checkweighing value that is being modified.

UNDER

UNDER allows entry of the lower checkweighing limits. It is also used to decrement a checkweighing value that is being modified.

Password Protected Values

To activate password protection, the **PASS** parameter must be configured with a numeric password. Once configured, password protection will be activated upon power up.

If password protection is activated, the display will show **PASS** when SETPOINT, TARE, UNDER, or OVER values are displayed. Password protection also inhibits deletion or creation of new product IDs. Enter the password and press ENTER, the display will then show **PASS** and then **OFF**. Protection is now disabled and values can be accessed and changed.

To reactivate password protection, press and hold ENTER for 2 seconds. The display will show **PASS**.

Battery Operation

The indicator can be optionally configured with a self-contained Rechargeable Sealed Lead-Acid battery and charging circuit, both internal. The scale is designed to run continuously for up to 60 hours with a single 350 ohm load cell. To maximize battery life, leave the auto-off timer enabled which will automatically power down the scale after a period of non-use.

Power Off

- 1) Manual - Press and hold the ZERO push button until the display turns off. The scale will not turn off if plugged in but will instead display “r E L P b”.
- 2) Automatic - At the end of the Unit On Timer (2.4 Edy) scale parameter setting. The scale will not turn off if plugged in.

Low Battery Indication



The battery annunciator indicates that the battery is in need of recharging. Once it turns on, there will be approximately one hour of battery life remaining before the scale turns off. Multiple load cells, USB, Bluetooth, Ethernet, 4-20mA and WiFi communications will reduce battery life.

Recharging Battery

To charge the battery, plug the line cord into a wall outlet. While the scale is charging, the battery annunciator will flash. The charging circuit will fully charge the battery in approximately eight hours. When the charging is complete, the annunciator will turn off. The scale can be used while recharging the battery.

Leaving the scale plugged in will ensure a fully charged battery and will not affect the life of the battery. The battery is able to support up to 1000 recharges. This is an estimate as many factors can affect battery life, including severe temperature changes and charging before the scale displays low battery.

Three Band Checkweighing

Three band checkweighing classifies weighments into over, accept and under. The default configuration is three band checkweighing. Note that lb:oz is not supported for checkweighing limits.

Three Band Checkweighing (9.1 L.O. set to operation starting with 3)

1. Remove all items from the scale platform
2. Press ZERO and the display will read zero weight
3. Place an item on the scale platform and wait for the scale to stabilize
4. Accept, Over or Under annunciators indicate checkweigh status

Enter and Display of Checkweigh Limits (9.2 L.E. default value 5Lr)

1. Press OVER or UNDER
2. The display will briefly read over or under followed by the current limit
3. Press either OVER to increase the weight value or press UNDER to decrease the weight value. Pressing and holding will accelerate the weight scroll.
4. Press ZERO to save the value or press PRINT to exit without saving
5. 5RULd is displayed if saved or RbOrL is shown if aborted

NOTE: To digitally adjust the platform weight for OVER and UNDER limits, the parameter L.E. must be set to 5L5.

Weight Reference and Digital Entry of Checkweigh Limits (9.2 L.E. set to 5L5)

1. Press ZERO
2. Place a target item on the scale
3. Press OVER or UNDER
4. The display will briefly read over or under followed by the weight on the platform
5. Press either OVER to increase the weight value or press UNDER to decrease the weight value. Pressing and holding will accelerate the weight scroll.
6. Press ZERO to save the value or press PRINT to exit without saving
7. 5RULd is displayed if saved or RbOrL is shown if aborted

NOTE: To digitally adjust the platform weight for OVER and UNDER limits, the parameter L.E. must be set to 5L5.

Weight Reference Entry of Checkweigh Limits (9.2 L.E. set to Pb)

1. Press ZERO
2. Place a weight equal to the desired OVER or UNDER limit on the platform
3. Press OVER or UNDER
4. over or under is displayed and then 5RULd to indicate the new OVER limit was saved.

NOTE: To enable Push-button entry of OVER and UNDER limits, the L.E. parameter must be set to Pb.

Five Band Checkweighing

Five band checkweighing classifies weighments into high, over, accept, under and low. Note that lb:oz is not supported for checkweighing limits.

Five Band Checkweighing (9.1 L.D. set to operation starting with 5)

1. Press ZERO
2. Place an item on the scale
3. Checkweigh status is indicated as follows
 - a. Flashing OVER = HIGH
 - b. Solid OVER = OVER
 - c. Solid ACCEPT = ACCEPT
 - d. Solid UNDER = UNDER
 - e. Flashing UNDER = LOW

Enter and Display of High and Low Limits (9.2 L.E. default value 55r)

1. Press and hold the OVER or UNDER until the display reads H, Ovr or L, ovr respectively
2. The current weight value of the saved limit is displayed and checkweigh status annunciators will flash
3. Press either OVER to increase the weight value or press UNDER to decrease the weight value. Pressing and holding will accelerate the weight scroll.
4. Press ZERO to save the value or press PRINT to exit without saving
5. 5555d is displayed if saved or 5555r is shown if aborted

NOTE: To digitally adjust the platform weight for OVER and UNDER limits, the parameter L.E. must be set to 55r.

Weight Reference and Digital Entry of High and Low Limits (9.2 L.E. set to 555)

1. Press ZERO
2. Place an item of the desired weight on the scale platform
3. Press and hold the OVER or UNDER until the display reads H, Ovr or L, ovr respectively
4. The current weight value of the saved limit is displayed and checkweigh status annunciators will flash
5. Press either OVER to increase the weight value or press UNDER to decrease the weight value. Pressing and holding will accelerate the weight scroll.
6. Press ZERO to save the value or press PRINT to exit without saving
7. 5555d is displayed if saved or 5555r is shown if aborted

NOTE: To digitally adjust the platform weight for OVER and UNDER limits, the parameter L.E. must be set to 555.

Weight Reference Entry of High and Low Limits (9.2 C.E. set to P6)

1. Press ZERO
2. Place an item of the desired weight on the scale platform
3. Press and hold the OVER or UNDER until the display reads H, Hh or L, Lh respectively
4. The display will briefly read OVER or UNDER followed by the weight on the platform and checkweigh status annunciators will flash
5. Press either OVER to increase the weight value or press UNDER to decrease the weight value. Pressing and holding will accelerate the weight scroll.
6. Press ZERO to save the value or press PRINT to exit without saving
7. SUCCESS is displayed if saved or ABORT is shown if aborted

NOTE: To enable Push-button entry of OVER and UNDER limits, the C.E. parameter must be set to P6.

Zero Band Checkweighing

Basic checkweighing - simply set the desired weight on the platform, press zero and checkweigh based upon the standard tolerances in the O.U. parameter (9.3 O.U.).

Zero Band Checkweighing (9.1 C.O. set to operation starting with 0)

1. Remove all items from the scale platform
2. Place the target weight on the scale platform
3. Press ZERO and the display will read zero weight
4. Remove the target weight
5. Place an item on the scale platform and wait for the scale to stabilize
6. A zero weight will indicate the item is exactly the target weight. Any weight above or below zero indicates the amount of weight away from the target weight.
7. Accept, Over or Under will be displayed

Product ID

800 product IDs are available. Deploying a large library of IDs with multiple scales can be easy to manage with Doran's QC Weigh and CheckWay data management programs.

Product IDs save information that includes:

- Checkweigh limits
- Unit of measure
- Accumulator and counter values
- Tare
- Two 40 alphanumeric character fields
- Number of samples and alarm timer for QC Weigh
- Motion Aperture (1.6 mm.)
- Threshold (2.5 tH5)
- Checkweigh operation (9.1 C.O.)
- Checkweigh limit entry (9.2 C.E.)
- Output configuration (9.7 out)

Recall PRODUCT ID from Memory

When powered on, no product ID will be loaded. This is indicated when pressing PROD ID and the display reads 000. Once a product ID is loaded, the unit of measure is locked in the unit of the product ID.

To select a stored product, press PROD ID, enter the ID number and press ENTER. The display will read 5854 to indicate the fields associated with that Product ID number are active. After selecting a product, the scale will measure and display in the units saved for that product. The UNITS button will then be disabled. Selecting product 'OFF' will re-enable the UNITS button.

Another method to select a product is to press PROD ID, then use the UNITS or PRINT buttons to scroll through the available products. Press ENTER to select the displayed product. The display will read 5854 to indicate the fields associated with that Product ID number are active.

Barcode Scan Recall PRODUCT ID from Memory

Press PROD ID to enter the Product ID recall mode. The display will show 1, followed by the current Product ID number. Using Doran's optional barcode scanner, scan the desired barcode. The display will confirm by showing the barcode value. To exit the ID edit mode, press PROD ID.

Display Current PRODUCT ID

Press PROD ID, the display will show 1 followed by the currently active product. Press ENTER to leave this mode.

Create New PRODUCT ID

Select the desired unit that will be used to checkweigh the new product. Enter a product ID up to 6 digits not currently in memory and press PROD ID. The display will

momentarily show **PROD ID** then **0**. Then return to weighing mode. All fields associated with the new Product ID number will be blank.

To enter and save values for all fields associated with the current Product ID, enter values for each field. When changing products, the display will read **SAVED** to indicate the all fields associated with the new Product ID number are saved and will be recalled when that product is used again.

Delete PRODUCT ID from Memory

Enter the product ID to be deleted and press PROD ID. The display will show **Prod ID**, followed by the product ID number. Press and hold the CLEAR button for more than 2 seconds. The display will show **CLR ID** and then **done**. The product ID will be set to off until another product ID is selected.

User ID

User ID login

With the display showing **LOG IN**, enter in through the keypad up to 20 digits for a user ID number. The User ID entered is compared with a list of up to 200 User IDs stored in the scale's memory). If a User ID entered does not match any of the stored IDs, the display will show **ERR, NO, USER** message.

Barcode Entry of User ID Values

Press PROD ID to enter the Product ID entry mode. Press Enter to advance to the User entry mode. The display will show **USER** followed by **0**. The scale has cleared the current User ID stored in memory. Using Doran's optional barcode scanner, scan the desired barcode. The display will read **-----** to represent the barcode value. If scanned value matches any of the User IDs stored in memory, the display will show **SAVED** and exit entry mode. If a User ID does not match, the display will show **ERR, NO, USER** message.

User ID Logout

Press and hold the CLEAR button for more than 2 seconds. The display will show **CLR USER**. Display will show **LOG IN** to indicate scale is disabled and requires a user id to login.

Product Fields

The 2200CW has eight 40-character alphanumeric fields that can be entered and transmitted as desired using custom data strings. In addition, there is a ninth product field for serialization which increments from the five digit number entered. This is useful for custom data labels and data collection.

Display Product Fields

To access Product Fields, press and hold PROD ID on the front panel for 3 seconds. The display will show "PF 1" for a second, then display the first 6 characters of the product field if they are numeric. The nine fields can be cycled through by pressing ENTER. Press PROD ID to exit from the Product Field mode.

Product Field Entry

To access Product Fields, press and hold PROD ID on the front panel for 3 seconds. The scale display will change from the current platform weight to show which Product Field is ready for entry. For the first field, the display will show "PF 1" for a second, then display the current entry of this field.

Product Fields can be entered by barcode, by external communications, or by the keypad on the front panel. When the indicator receives a barcode scanner transmission completed by a carriage return it will accept the scanned field automatically when the field number is active. If the scanned item is alphanumeric only, press enter to accept the scanned field. A keypad entry followed by pressing ENTER, will store the entered value as that Product Field. Once entered, the scale will then display the next Product Field, in this case "PF 2". The scale will cycle through the 9 Product Fields unless the user presses PROD ID again, which will exit from the Product Field mode.

QC Weigh Operation

The 2200CW is capable of automatic checkweigh operation. Through use of our external data management program, ionSuite, users can: input custom products, input unique users, and run reports on the data collected. See the Product ID and User ID sections of this manual for more information of what can be input. QC Weigh requires either the Ethernet or WiFi options to function.

QC Weigh Mode

When adding the scale to ionSuite, it tests the connection to the scale and changes the operation to QC Weigh Mode.

If needed, the configuration can be changed manually as well. To do so, enter the scale's Calibration and Parameter Setup Mode, then change parameter 1.12, Operating Mode, to "0.12", or QC Weigh. This process is detailed in the Scale Parameter Setup section.

Entering a User ID

When in QC Weigh mode, the scale will display "0.00 g". Users can be added by selecting any scale on the QC Weigh network, selecting the Scale Login Tab and adding users. Once created, the users must be saved to all scales.

After putting the scale into QC Weigh Mode, the scale will read "0.00 g". The scaler can use one of two methods to input their User ID:

The User ID can be scanned off a barcode. Scanning a valid User ID will automatically advance to the next screen.

The User ID can be manually input using the keypad, then press ENTER to advance to the next screen.

Entering a Product ID

Ensure that Product IDs are stored on the indicator before attempting to enter a Product ID. This process is done in ionSuite. Product IDs can be up to 20 alphanumeric characters in length. The last 6 characters are displayed on the LED screen. To recall alphanumeric or Product IDs longer than 6 characters, a barcode scanner is suggested.

After a User ID has been entered, a new screen will appear showing the stored Product IDs. The scaler can use one of three methods to input their Product ID:

The Product ID can be scanned off a barcode. Scanning a valid Product ID will automatically advance to the next screen.

The Product ID can be manually selected. Use the UNITS and PRINT buttons on the scale to scroll forward or backwards respectively. Once highlighting the desired Product ID, press ENTER to advance to the next screen.

A numeric Product ID can be entered via the keypad and press ENTER

Selecting “OFF” then ENTER will exit Product ID and return to “LOG IN”

Checkweigh Operation

Once a valid User ID and Product ID is enabled, the checkweigh process will begin. Operation goes as follows:

Alarm Timer:

When checkweighing begins, a timer defined in the Product ID will begin to count down. If this counter reaches 0, “LATE” will appear. Any samples taken after late is displayed will be counted as late in ionSuite reports, as well as trigger output 1 and the optional light tower.

Sample Number:

Whenever a sample is weighed, a “c” will appear for 3 seconds, indicating that a stable reading was saved for that sample. When the stable weight is achieved, the weight is locked and immediately transmitted to ionSuite. Once the sample is removed, the next sample number will flash on the scale. Once all samples are completed on a product, “DONE” will appear on the scale, and will begin the alarm countdown sequence.

Exiting:

During either the process of entering a product or checkweighing, press and hold “CLEAR” to return to the “LOG IN” screen.

ionSuite Syncing of Product IDs and User IDs

To sync User IDs and Product IDs to the scale, the scale must be in login mode. Only sync to the scale when the scale displays “LOG IN”.

Time and Date

Setting Time and Date

To change the date:

1. Press and hold decimal point / clock button until 00.00 is displayed
2. The display flashes the current the date
3. The digits being edited flashes on the display
4. Enter the date with leading zeros in the format MM.DD.YY
5. Press UNITS to advance to the next digit
6. Press UNITS until the display reads 00.00 to confirm the date changes are saved
7. Press ENTER to return to the normal weighing mode.

To change the time:

1. Press and hold decimal point / clock button until 00.00 is displayed
2. Press the decimal point button
3. The display reads 00.00 when the time in 24hour format is displayed
4. The digit that being edited flashes on the display
5. Enter the time with leading zeros in the format HH.MM.SS
6. Press UNITS to advance to the next digit
7. Press UNITS until the display reads 00.00 to confirm the time changes are saved
8. Press ENTER to return to the normal weighing mode.

Accumulator and Counter

Accumulator and Counter Operation

When a manual or automatic print function is executed, the accumulator has the currently displayed weight added to its' current value and the counter is incremented. To accumulate automatically, select an auto print function in the parameter setup menu.

To accumulate manually, allow the scale to become stable and press PRINT.

The maximum value that can be shown for the accumulator and counter is 999,999. When the maximum value is reached, the accumulator and counter will rollover to a zero value. If displayed units are changed, the accumulator is cleared. This feature can only be used in a non Legal For Trade application.

Display Accumulator and Counter Values

Press the ACCUM button to enter the accumulator and counter recall mode. The display will show $\overline{\text{ACCUM}}$ followed by the accumulated weight in the units currently selected in the weigh mode. Then $\overline{\text{COUNT}}$ will be displayed followed by the counter value.

Press ACCUM to exit the accumulator and counter recall mode without changing their values.

Clear Accumulator and Counter

Press the ACCUM button to enter the accumulator and counter recall mode. The display will show $\overline{\text{ACCUM}}$ followed by the accumulated weight in the units currently selected in the weigh mode. Then $\overline{\text{COUNT}}$ will be displayed followed by the counter value.

Press CLEAR to clear the accumulator and counter values. The display will show $\overline{\text{CLR ACC}}$ and exit from the recall mode.

Changing the current display units will clear both the accumulator and counter values.

Accumulator and Counter Data String Output to Printer or Data Collection

Press ACCUM to enter the accumulator recall mode. Press PRINT to transmit the LB4 custom data string that contains the accumulator and counter values by default. Both the accumulator and counter values are cleared after transmission.

Installation Guide




Fig. 2: Motherboard Layout

Removing and Replacing the Rear Panel

Before you remove the rear panel, remove AC power. Power down the scale if the optional battery power is present. Removing the rear panel requires a 5/16" nut driver.

To replace the rear panel and achieve a tight seal, each screw requires a rubber bonded washer and the gasket needs to be in place. Tighten screws to 20 in-lb to achieve proper sealing. Tighten all watertight glands until the cable exiting the watertight can no longer slide through the watertight – this is usually finger tight plus a quarter turn with a wrench to seal.

Heartbeat LED

Between the keypad connection and the microprocessor exists a green heartbeat LED. When this LED is blinking, it indicates that the microprocessor has successfully loaded software and is receiving power. This light can be turned on or off, as detailed in the "Remote Commands" section.

Load Cell Connection

Load cell connections are made through terminal block TB1. The power cord connects to terminal block TB5 adjacent to the transformer.




Fig. 3: Load Cell and Power (lower left of board)

	4 wire load cell	6 wire load cell
J1 Jumper	In	Out
J2 Jumper	In	Out

Load Cell Input (TB1)		
	Description	Load Cell Color Code
+ SIG	+ Signal	Red
- SIG	- Signal	White
+ EX	+ Excitation	Green
- EX	- Excitation	Black
+ SEN	+ Sense Signal	Blue
- SEN	- Sense Signal	Brown

Power Connection and Fuse

Power input is located at terminal block TB5, next to the fuse and black transformer.

Neutral	Ground	Line (Hot)
N	G	L

Make sure power is off before replacing the fuse. The scale's fuse (F1) is located next to the power terminal (J1).

The scale has a filtered power supply to reduce the effects of normal line noise, but it cannot limit severe fluctuations. Be sure the AC power is not excessively noisy. If problems occur, noise producing devices may have to be suppressed to minimize their effect.

RS232 and Remote Switch Connection

The Remote Switch and Serial Communications are located in the TB3 terminal block. Option cables are passed through watertight glands mounted on the rear cover of the indicator.





Fig. 4: Output Serial and Remote Switch Connection (upper right of board)

TB3 RS232 and Remote Switch Connections	
	Description
RX1	RS232 Port 1 Receive (RXD)
TX1	RS232 Port 1 Transmit (TXD)
GND	Common Ground
SW1	Remote Switch 1 Input
SW2	Remote Switch 2 Input
RX2	RS232 Port 2 Receive (RXD)
TX2	RS232 Port 2 Transmit (TXD)
GND	Remote Switch Common
VDC	4.7Vdc

RS232 Output DB9 Female Connector Wiring		RS232 Output DB9 Male Pin Wiring	
	Female Description		Male Description
2	(TXD) Transmitted Data	(RXD) Received Data	
3	(RXD) Received Data	(TXD) Transmitted Data	
5	(GND) Ground	(GND) Ground	

Output Connections

Each output point consists of a current-sinking Darlingtion pair with a transient – suppression diode connected to +V. Jumpers JU7 and JU3 control whether +V is board-supplied 4.7 VDC or 12 VDC. One or the other jumper needs to be installed for output operation, but never both. The maximum current sinkable through a single output is 500mA. If using board-supplied voltage, the maximum total current available is 800 mA.



Calibration Guide

Entering Calibration and Parameter Setup Mode

Front Panel Access

1. Press and hold ZERO and UNITS simultaneously until the audit counters are displayed.
2. $\bar{E}n\bar{t}$ $\bar{C}d$ is displayed
3. Press ZERO 5 times, so that $\bar{5}$ is displayed,
4. Press UNITS

Internal Calibration Button

The calibration push button is located near the center of the board and labeled CAL. Press this button to enter calibration and setup.

Exit Calibration and Parameter Setup Mode

Front Panel Access

1. Press UNITS until the display reads $\bar{9}9$. $\bar{d}0n$.
2. Press the ZERO button
3. The display reads $\bar{d}0n\bar{E}n$
4. Press the ZERO button
5. The display reads $\bar{d}0n\bar{E}5$
6. Press UNITS to return to the run mode
7. Display reads $\bar{5}R\bar{W}\bar{E}d$ to confirm changes are saved to memory

Internal Calibration Button

The calibration push button is located near the center of the board and labeled CAL. Press this button to exit calibration and save settings.

Set Scale Capacity

The Capacity selection is displayed after entering the Calibration and Setup mode.

1. $\bar{1}$ $\bar{C}R\bar{1}$ is displayed
2. Press ZERO
3. The display will alternate between $\bar{C}R\bar{0}$ $\bar{R}d$ and the currently selected capacity
4. Press ZERO to change the capacity
5. The units annunciator will flash indicating the unit of measure for the capacity. Press ZERO to change the unit of measure if required.
6. Press PRINT
7. The right most digit will flash. Press ZERO to change this number from $\bar{0}$ to $\bar{9}$.
8. Press PRINT to move to the next digit to the left.
9. Repeat until all digits have been set to the desired scale capacity.
10. Once the digits have been set, the display will return to alternately displaying $\bar{C}R\bar{0}$ $\bar{R}d$ and the new capacity value.

Set Scale Count By

After the capacity has been entered, count by(resolution) will automatically be set for a legal for trade 5000 division level.

1. After calibration, press UNITS.
2. The display will alternate between $\overline{C}n\overline{t}b\overline{y}$ and the current count by
3. Press ZERO to select the desired count by
4. To exit and save changes, press UNITS until $\overline{d}n\overline{E}n$ is displayed.
5. Press ZERO
6. $\overline{d}n\overline{E}y$ will be displayed
7. Press UNITS to return to the run mode

Calibration

After count by has been set, calibration is required

1. Press UNITS until $\overline{C}n\overline{L}0$ appears on the display
2. Remove all weight from the scale platform
3. Press ZERO and wait for the display to count down to 0
4. The display will alternate between $\overline{C}n\overline{L}F5$ and the scale capacity
5. Place the calibration weight on the scale platform (2% of capacity to full capacity)
6. If calibrating at scale capacity, press ZERO to begin calibration and move to step 12. If not calibrating at the scale capacity, continue to step 7.
7. Press PRINT
8. The right most digit will flash. Press ZERO to change this number from 0 to 9.
9. Press PRINT to move to the next digit to the left
10. Repeat until all digits have been set to the desired calibration weight
11. Press PRINT and the calibration process will begin and the display will count down to zero.
12. The display will momentarily display $\overline{d}n\overline{E}n$, followed by $\overline{S}n\overline{u}E\overline{d}$ and return to the normal weighing mode
13. Verify scale calibration

NOTE: Calibration at 2% of capacity has been provided as a convenience to customers with scales in inaccessible locations. Scales calibrated at 2% will not be as accurate at full capacity compared to scales calibrated at full capacity. It is the responsibility of the installer to ensure that scale accuracy is achieved after any calibration.

Calibration Error Codes

Code	Solution
$\overline{S}n\overline{u}n\overline{E}$	The calibration span is out of range. Press ZERO to clear this error. Refer to the Scale Calibration Error Troubleshooting section.
$\overline{E}r\overline{r}n\overline{R}$	The scale is sensing an unstable weight. Remove any vibration or air currents to continue calibration.

Scale Calibration Error Troubleshooting

The allowable load cell signal input range is 0.30 mV/V to 5.0 mV/V.

1. Calculate scale divisions by dividing the scale capacity by the count by.
Example: For a 50 x 0.01 lb scale, divide 50 by 0.01 for a result of 5000d
2. Enter the calibration and parameter setup mode.
3. Press PRINT until the configuration menu $\overline{\text{CAL}} \overline{\text{F}} \overline{\text{G}}$ is displayed.
4. Press ZERO to enter the configuration menu.
5. Press UNITS until the scale counts are displayed.
6. Remove all items from the platform and record the zero load scale counts reading.
7. Place full capacity on the platform and record the scale counts.
8. Subtract the zero load counts from the full load counts to calculate the span.
9. The span number, from step #7, must be higher than the scale divisions found in step #1.

The maximum span, at full load is 750,000. If the span is higher, the span calibration will not be accepted.

If the span counts are too low or too high, check the load cell connections. If the connections are correct, replace the load cell.

Scale Parameter Setup

Entering Calibration and Parameter Setup Mode

Front Panel Access

1. Press and hold ZERO and UNITS simultaneously until the audit counters are displayed.
2. 0.00 is displayed
3. Press ZERO 5 times, so that 5 is displayed,
4. Press UNITS

Internal Calibration Button

The calibration push button is located near the center of the board and labeled CAL. Press this button to enter calibration and setup.

Exit Calibration and Parameter Setup Mode

Front Panel Access

1. Press UNITS until the display reads 0.00.
2. Press the ZERO button
3. The display reads 0.00
4. Press the ZERO button
5. The display reads 0.00
6. Press UNITS to return to the run mode
7. Display reads 0.00 to confirm changes are saved to memory

Internal Calibration Button


The calibration push button is located near the center of the board and labeled CAL. Press this button to exit calibration and save settings.

Navigating Parameter Menu with Keypad

To navigate to a specific parameter, first enter calibration and parameter setup mode, as described above. Then, enter the parameter group number, a decimal point, and the element number, followed by the ENTER button. These values are located to the left of each parameter outlined later.

Navigating Parameter Menu with ZERO, UNITS, and PRINT

Press UNITS and PRINT navigate to the desired top level parameter group. Enter the group by pressing ZERO. Once within a group, press UNITS to advance, PRINT to back up and ZERO to change the currently displayed parameter setting.



Parameter Groups

The scale parameters are divided up into eight parameter groups. Each group contains related parameters. Below is a brief list describing each parameter group.

1 CAL	Capacity and Calibration
2 CNFG	General Settings
3 SER 1	Serial port #1
4 SER 2	Serial port #2
5 ETH	Ethernet
6 WLF	Wireless Ethernet
7 BT	Bluetooth
8 USB	USB
9 OPE	Checkweigh Operation
99 DON	Exit Setup

Legal for Trade Restrictions

When the Legal for Trade mode is enabled, it automatically disables some menus and parameter options. This is done to comply with NTEP and CWM requirements. The menus and parameter sections are shown on the following pages. Menus and parameters not available when in the Legal for Trade mode are marked by an asterisk.

Audit Counters

When entering calibration mode, the Parameter audit counter and the Calibration audit counter will momentarily be displayed. The Parameter audit counter increments when legal for trade values are changed. The Calibration audit counter increments when the scale is calibrated.

Software Part Number and Revision Level

During the front panel access procedure, the scale will display the software number and revision. The software number is $5u \text{ } 19 \text{ } 1$ followed by the software revision level $r \text{ } 1u$.

Please have the software number $19 \text{ } 1$ and the revision level available when contacting our technical support department.

Capacity and Calibration - [CAL]

1.1	[CAP ADJ]	Capacity Adjustment
	1 - 999000	1 lb / kg to 999,000 lb / kg Refer to calibration guide for more detail

1.2	[CntBy]	Count By Setup Menu Also known as resolution or division
	0.00002 5000	Selection limited by scale capacity Capacity/resolution (scale divisions) maximum value is 50,000d and minimum value is 200d

1.3	[CAL]	Calibration Mode
	0	Calibration Zero Press ZERO to perform calibration of the scale zero Successful calibration is indicated by "[CAL FS]"
	XXXXXX	Only appears after a successful zero calibration Enter calibration weight through keypad and decimal point if required.

1.4	[Filt]	Display Filter Setting Determines speed of digital filtering
	1	Fastest display updates, most sensitive setting
	2	Default Setting
	4	
	8	
	16	
	32	
	64	Slowest display updates, least sensitive setting

1.5	RZt*	Automatic Zero Tracking Range Weight within the specified number of divisions are automatically zeroed
	oFF	Zero tracking is off, no automatic zeroing
	0.5	Zero tracking to within 0.5 division
	1*	Zero tracking to within 1 division
	3*	Zero tracking to within 3 divisions
	5*	Zero tracking to within 5 divisions
	10*	Zero tracking to within 10 divisions
	20*	Zero tracking to within 20 divisions

1.6	nn.R.*	Motion aperture* Determines the number of divisions that consecutive readings must change before the scale is considered to be in motion
	0.5*	0.5 divisions
	1	1 division
	2*	2 divisions
	3*	3 divisions
	5*	5 divisions
	10*	10 divisions

1.7	nn.d*	Motion Delay* Length of a motion indication display.
	1 - 9	Length of a motion indication display, in 100ms intervals. Default is 3. (Locked to 3 in Legal for Trade mode)

1.8	SVZ*	Start Up Zero Controls the zero point when the scale is turned on
	oN	Zeros on the first stable reading on power up
	CLZ	Loads the calibration zero point
	PbZ*	Loads the last pushbutton zero

1.9	tRr	Tare Input
	PbN	Tare Pushbutton as well as keypad entry
	Pb	Tare Pushbutton only
	n	Keypad only
	oFF	No tare entry

*Parameters not available in Legal for Trade mode

1.10	Z_{od}	Zero on Demand Enables or disable zero latching
	on	If ZERO is pressed, it is saved until the scale becomes stable.
	off	If the scale is in motion, the zero request is discarded.

1.11	P_{od}	Print on Demand Enables or disables print latching
	on	If PRINT is pressed, the print request is saved until the scale becomes stable.
	off	If the scale is in motion, the print request is discarded.
	not	Print when requested, whether the scale is in motion or not

1.12	o^P	Operating Mode
	Std	Standard operation
	44	NTEP legal-for-trade. Restricts parameters to keep them within NTEP limits.
	445	CWM legal-for-trade. Restricts parameters to keep them within CWM limits.
	0.00	QC Weigh mode. In this mode, PROD ID, GROSS/NET, ACCUM, OVER, UNDER, SETPOINT, and TARE buttons are disabled.
	Pr5	Production Sentry mode. In this mode, GROSS/NET, ACCUM, OVER, UNDER, SETPOINT, and TARE buttons are disabled.

1.14	done	Exit Calibration and Setup
	y	Saves and exits setup when PRINT or UNITS is pressed.
	n	Remains in setup

General Settings - 2 [nF9]

2.1	[5L]	Unit Enable and Disable Determines which unit selections will be active
	no	Do not enter Convert selection menu
	YES	Enter Convert selection menu
	lb	pounds menu
	on	lb is active
	off	lb is non active
	kg	kilograms menu
	on	kg is active
	off	kg is non active
	oz	ounces menu
	on	oz is active
	off	oz is non active
	gr	grams menu
	on	g is active
	off	g is non active
	lb	pound:ounce menu
	on	lb:oz is active
	off	lb:oz is non active

NOTE: oz units are disabled for capacities greater than 60,000 lb
grams units are disabled for capacities greater than 2000 lb
lb:oz are only available for capacities between 10 and 1000 lb

2.2	Unit 5	Start Up Units Select Mode Configures selection of startup units
		The unit annunciator, to the right of the display, indicates the active unit on power up. Press ZERO to change the selection.

2.3	P.b.	Push Button Enable and Disable Determines which buttons are active or inactive
no		Do not enter push button selection menu
yes		Enter push button selection menu
	P_r	PRINT button
	on	pb is active
	off	pb is non active
	U_t	UNITS button
	on	pb is active
	off	pb is non active
	Z_r	ZERO button
	on	pb is active
	off	pb is non active
	r 1, r 2	REMOTE SWITCH 1 and 2 function
	off	Remote pb is non active
	Z _r	ZERO
	P _r	PRINT
	U _t	UNITS
	A _c	ACCUM
	t _r	TARE
	G _n	GROSS NET
	o_u	Over and Under buttons
	on	pb is active
	off	pb is not active
	G_n	GROSS NET button
	on	pb is active
	off	pb is not active
	A_c	ACCUM button
	on	pb is active
	off	pb is not active (disables accumulator function)
	S_P	SETPPOINT button
	on	pb is active
	off	pb is non active
	t_r	TARE button
	on	pb is active
	off	pb is non active
	i_d	PRODUCT ID button
	on	pb is active
	off	pb is non active

2.4	ቴዕሃ	Automatic off Timer Only visible when ሌዳቴቴ parameter is set to ሃ
	ፀጎ	Unit will remain on, On timer is off
	0.5	30 second On timer
	1	1 minute On timer
	1.5	1.5 minute On timer
	2	2 minute On timer
	3	3 minute On timer
	5	5 minute On timer
	10	10 minute On timer
	30	30 minute On timer
	1hr	1 hour On timer
	2hr	2 hour On timer
	4hr	4 hour On timer
	8hr	8 hour On timer

2.5	ቴዳኗ	Threshold Level Entry Controls some printing features, setpoints, and outputs
	0.1 - 9.9	$\pm 0.1\%$ to $\pm 9.9\%$ of capacity Default setting is 1%

2.6	ዳፎቴ	Default Used to set parameters to factory default values
	n	Do not default
	ሃ	Set parameters to default values

2.7	Counts	Raw counts from the AD converter Used for troubleshooting during calibration
	xxxxxx	-99999 to 999999

2.8	ኮፖቴ	Controls the brightness of all LEDs
	1-15	Can be set to a value of 1 to 15 with 15 being the brightest. Default value is 9. Note: Decreasing brightness conserves battery life.

2.9	ኮዳቴቴ	Enable or disable battery operation
	n	Battery option not installed
	ሃ	Battery option installed

2.10	PR55	Enable or disable password
	n	Password inactive
	y	Password active – press UNITS, enter numeric password and press ENTER. The password must be a minimum of 3 digits and no longer than 6 digits.

Serial (RS232) Port 1 - 3 5Er :

3.1	d.o. :	Data Output Mode Port 1
	t.o.d.	Transmit on demand. Transmit when the PRINT button is pressed.
	R.P.1	Auto Print 1. Transmit once only when scale becomes stable.
	R.P.2	Auto Print 2. Transmit once only when scale becomes stable. Scale must return to, or below, the threshold range (2.5 tH5).
	R.P.3	Auto Print 3. Transmit once when the scale stabilizes within the ACCEPT range. Weight must fall below the threshold value (2.5 tH5) before transmitting again.
	R.P.4	Auto Print 4. Transmit first stable weight outside of threshold. Transmission happens when weight returns to threshold range (2.5 tH5).
	R.P.5	Auto Print 5. Transmit the last stable weight outside of threshold. Transmission happens when weight returns to threshold range (2.5 tH5).
	t1	Transmits every 1 second.
	t5	Transmits every 5 seconds.
	t60	Transmits every 60 seconds.
	CP	Continuous Print. Transmit when display is updated. Approximately every 1/10 th of a second.
	oFF	Port disabled

Note: only one communication port can have a timed output mode (t1, t5, t60, or CP)

3.2	For. :	Data Output Format Port 1
	F0	Basic output format
	2d	Basic Dual Print Format. Includes Kilogram weight.
	SSP	Basic Output for label printer
	F9	Model 8000 emulation
	Lb1	User definable print string with default values
	Lb2	User definable print string with default values
	Lb3	User definable print string with default values
	Lb4	User definable print string

ba	WinSPC compatibility format
----	-----------------------------

3.3	br. 1	Baud Rate Port 1
	12	1200 baud
	24	2400 baud
	48	4800 baud
	96	9600 baud
	14.4	14,400 baud
	19.2	19,200 baud
	28.8	28,800 baud
	38.4	38,400 baud

Serial (RS232) Port 2 - 45Er2

4.1	d.o. 2	Data Output Mode Port 2
	t.o.d.	Transmit on demand. Transmit when the PRINT button is pressed.
	A.P. 1	Auto Print 1. Transmit once only when scale becomes stable.
	A.P. 2	Auto Print 2. Transmit once only when scale becomes stable. Scale must return to, or below, the threshold range (2.5 tH5).
	A.P. 3	Auto Print 3. Transmit once when the scale stabilizes within the ACCEPT range. Weight must fall below the threshold value (2.5 tH5) before transmitting again.
	A.P. 4	Auto Print 4. Transmit first stable weight outside of threshold. Transmission happens when weight returns to threshold range (2.5 tH5).
	A.P. 5	Auto Print 5. Transmit the last stable weight outside of threshold. Transmission happens when weight returns to threshold range (2.5 tH5).
	t1	Transmits every 1 second.
	t5	Transmits every 5 seconds.
	t60	Transmits every 60 seconds.
	CP	Continuous Print. Transmit when display is updated. Approximately every 1/10 th of a second.
	off	Port disabled

Note: only one communication port can have a timed output mode (t1, t5, t60, or CP)

4.2	For. 2	Data Output Format Port 2
	F0	Basic output format
	2d	Basic Dual Print Format. Includes Kilogram weight.
	55P	Basic Output for label printer
	F9	Model 8000 emulation
	Lb1	User definable print string with default values
	Lb2	User definable print string with default values
	Lb3	User definable print string with default values
	Lb4	User definable print string
	ba	WinSPC compatibility format

4.3	br. 2	Baud Rate Port 2
	12	1200 baud
	24	2400 baud
	48	4800 baud
	96	9600 baud
	14.4	14,400 baud
	19.2	19,200 baud
	28.8	28,800 baud
	38.4	38,400 baud

Wired Ethernet - 5 Eth

5.1	d.o. E	Data Output Mode Ethernet
	t.o.d.	Transmit on demand. Transmit when the PRINT button is pressed.
	R.P.1	Auto Print 1. Transmit once only when scale becomes stable.
	R.P.2	Auto Print 2. Transmit once only when scale becomes stable. Scale must return to, or below, the threshold range (2.5 tH5).
	R.P.3	Auto Print 3. Transmit once when the scale stabilizes within the ACCEPT range. Weight must fall below the threshold value (2.5 tH5) before transmitting again.
	R.P.4	Auto Print 4. Transmit first stable weight outside of threshold. Transmission happens when weight returns to threshold range (2.5 tH5).
	R.P.5	Auto Print 5. Transmit the last stable weight outside of threshold. Transmission happens when weight returns to threshold range (2.5 tH5).
	t1	Transmits every 1 second.
	t5	Transmits every 5 seconds.
	t60	Transmits every 60 seconds.
	C.P.	Continuous Print. Transmit when display is updated. Approximately every 1/10 th of a second.
	C.P. UDP	Continuous Print. Transmit on selected UDP port when display is updated. Approximately every 1/10 th of a second.
	oFF	Port disabled

Note: only one communication port can have a timed output mode (t1, t5, t60, or CP)

5.2	For. E	Data Output Format Ethernet
	F0	Basic output format
	2d	Basic Dual Print Format. Includes Kilogram weight.
	SSP	Basic Output for Label printer
	F9	Model 8000 emulation
	Lb1	User definable print string with default values
	Lb2	User definable print string with default values
	Lb3	User definable print string with default values
	Lb4	User definable print string
	ba	WinSPC compatibility format

5.3	.P.xxxx	Static or DHCP IP Address Assignment
	.P.dhCP	DHCP - address supplied by network server

	ᄀ.ᄀᄀᄀᄀ	Static - address assigned at indicator
5.4	ᄀᄀ ᄀᄀᄀ	Static IP Address Assignment
		Current IP address of the scale. Cannot be changed if the previous parameter is set to DHCP
5.5	ᄀᄀᄀᄀᄀ	Subnet Mask
		Current subnet setting. Cannot be changed if set for DHCP
5.6	ᄀᄀᄀᄀ	IP Gateway
		Current IP Gateway. Cannot be changed if set for DHCP
5.7	ᄀᄀᄀᄀ	TCP Port Number
	xxxxx	Indicates the listening TCP port number of the scale
5.8	ᄀᄀᄀᄀᄀ	Ethernet MAC Address
	xxxxxx.xxxxxx	The unique Ethernet MAC address. Cannot be changed.
5.9	ᄀᄀᄀᄀ	4mA point adjustment
	0-255	Use this value to adjust the 4mA output, if that option is installed on your scale. Default is 127 .
5.10	ᄀᄀᄀᄀᄀ	20mA point adjustment
	0-255	Use this value to adjust the 20mA output, if that option is installed on your scale. Default is 127 .

5.11	UDP .P	UDP IP Address
		Current IP address that the scale will use to send UDP packets.

5.12	U Port	UDP Port Number
	xxxxx	Indicates the transmission UDP port number of the scale.

Wireless Ethernet – 6 u u F ,

6.1	d.o. UU	Data Output Mode wifi
	t.o.d.	Transmit on demand. Transmit when the PRINT button is pressed.
	A.P.1	Auto Print 1. Transmit once only when scale becomes stable.
	A.P.2	Auto Print 2. Transmit once only when scale becomes stable. Scale must return to, or below, the threshold range (2.5 tH5).
	A.P.3	Auto Print 3. Transmit once when the scale stabilizes within the ACCEPT range. Weight must fall below the threshold value (2.5 tH5) before transmitting again.
	A.P.4	Auto Print 4. Transmit first stable weight outside of threshold. Transmission happens when weight returns to threshold range (2.5 tH5).
	A.P.5	Auto Print 5. Transmit the last stable weight outside of threshold. Transmission happens when weight returns to threshold range (2.5 tH5).
	t1	Transmits every 1 second.
	t5	Transmits every 5 seconds.
	t60	Transmits every 60 seconds.
	C.P.	Continuous Print. Transmit when display is updated. Approximately every 1/10 th of a second.
	oFF	Port disabled

Note: only one communication port can have a timed output mode (t1, t5, t60, or CP)

6.2	For. UU	Data Output Format wifi
	F0	Basic output format
	Zd	Basic Dual Print Format. Includes Kilogram weight.
	SSP	Basic Output for label printer
	F9	Model 8000 emulation
	Lb1	User definable print string with default values
	Lb2	User definable print string with default values
	Lb3	User definable print string with default values
	Lb4	User definable print string
	bo	WinSPC compatibility format

6.3	.P.xxxx	Static or DHCP IP Address Assignment
	.P.dhCP	DHCP - address supplied by network server
	.P.StAt	Static - address assigned at indicator

6.4	.P Adr	Static IP Address Assignment
		Current IP address of the scale. Cannot be changed if the previous parameter is set to DHCP.

6.5	Subnet	Subnet Mask
		Current subnet setting. Cannot be changed if set for DHCP

6.6	Gate	IP Gateway
		Current IP Gateway. Cannot be changed if set for DHCP

6.7	Port	TCP Port Number
	xxxxx	Indicates the listening TCP port number of the scale.

6.8	Idle	Idle Timeout
0 - 65536		<p>Number of seconds during which no data is transmitted or received before the connection is automatically closed. Default is 0 seconds.</p> <p>Setting the timer to 0 prevents disconnecting.</p>

6.9	MAC	Ethernet MAC Address
xxxxxx.xxxxxx		The unique Ethernet MAC address. Cannot be changed.

6.10	WiFi	Wifi Connection Status
		<p>8 - The unit is not connected 88 - The unit is connecting. 888 - The unit is connected</p> <p>There is no entry on this screen. This is a display that reports the wifi connection status.</p>

Bluetooth – 7 bt

7.1	d.o. bt	Data Output Mode Bluetooth
	t.o.d.	Transmit on demand. Transmit when the PRINT button is pressed.
	A.P.1	Auto Print 1. Transmit once only when scale becomes stable.
	A.P.2	Auto Print 2. Transmit once only when scale becomes stable. Scale must return to, or below, the threshold range (2.5 tH5).
	A.P.3	Auto Print 3. Transmit once when the scale stabilizes within the ACCEPT range. Weight must fall below the threshold value (2.5 tH5) before transmitting again.
	A.P.4	Auto Print 4. Transmit first stable weight outside of threshold. Transmission happens when weight returns to threshold range (2.5 tH5).
	A.P.5	Auto Print 5. Transmit the last stable weight outside of threshold. Transmission happens when weight returns to threshold range (2.5 tH5).
	t1	Transmits every 1 second.
	t5	Transmits every 5 seconds.
	t60	Transmits every 60 seconds.
	C.P.	Continuous Print. Transmit when display is updated. Approximately every 1/10 th of a second.
	oFF	Port disabled

Note: only one communication port can have a timed output mode (t1, t5, t60, or CP)

7.2	For. b	Data Output Format Bluetooth
	F0	Basic output format
	2d	Basic Dual Print Format. Includes Kilogram weight.
	55P	Basic Output for label printers
	F9	Model 8000 emulation
	Lb1	User definable print string with default values
	Lb2	User definable print string with default values
	Lb3	User definable print string with default values
	Lb4	User definable print string
	ba	WinSPC compatibility format

USB - 8 55b

8.1	d.o. 55b	Data Output Mode USB
	t.o.d.	Transmit on demand. Transmit when the PRINT button is pressed.
	A.P.1	Auto Print 1. Transmit once only when scale becomes stable.
	A.P.2	Auto Print 2. Transmit once only when scale becomes stable. Scale must return to, or below, the threshold range (2.5 tH5).
	A.P.3	Auto Print 3. Transmit once when the scale stabilizes within the ACCEPT range. Weight must fall below the threshold value (2.5 tH5) before transmitting again.
	A.P.4	Auto Print 4. Transmit first stable weight outside of threshold. Transmission happens when weight returns to threshold range (2.5 tH5).
	A.P.5	Auto Print 5. Transmit the last stable weight outside of threshold. Transmission happens when weight returns to threshold range (2.5 tH5).
	t1	Transmits every 1 second.
	t5	Transmits every 5 seconds.
	t60	Transmits every 60 seconds.
	C.P.	Continuous Print. Transmit when display is updated. Approximately every 1/10 th of a second.
	oFF	Port disabled

Note: only one communication port can have a timed output mode (t1, t5, t60, or CP)

8.2	For. 55b	Data Output Format USB
	F0	Basic output format
	2d	Basic Dual Print Format. Includes Kilogram weight.
	55P	Basic Output for label printers
	F9	Model 8000 emulation
	Lb1	User definable print string with default values
	Lb2	User definable print string with default values
	Lb3	User definable print string with default values
	Lb4	User definable print string
	ba	WinSPC compatibility format

Checkweigh and Output Operation – 9 0PEr

9.1	Code	Checkweigh Operation
	3A	Three band checkweighing Checkweigh status continuously active.
	35	Three band checkweighing Only active while weight is stable and inactive while the scale is in motion.
	3E	Three band checkweighing Only active while the weight is above the threshold value (2.5 tH5) and inactive when below.
	3EL	Three band checkweighing Only active while weight is above the threshold value. Once OVER is activated, it will remain active until the weight falls below the threshold value (2.5 tH5).
	3b	Three band checkweighing Only active while weight is stable and above the threshold value (2.5 tH5). Inactive while the scale is in motion or below the threshold value.
	3bL	Three band checkweighing Only active while the weight is stable and above the threshold value (2.5 tH5). OVER will remain active until the weight falls below the threshold. UNDER and ACCEPT deactivate while the scale is in motion or below the threshold value.
	5A	Five band checkweighing Continuously active
	55	Five band checkweighing Only active while weight is stable and inactive while the scale is in motion.
	5E	Five band checkweighing Only active while the weight is above the threshold value (2.5 tH5) and inactive when below.
	5b	Five band checkweighing Only active while weight is stable and above the threshold value (2.5 tH5). Inactive while the scale is in motion or below the threshold value.
	0A	Zero band checkweighing Continuously active See 0.0. parameter (9.3 0.0.) for tolerance values
	05	Zero band checkweighing Active only when the scale is stable See 0.0. parameter (9.3 0.0.) for tolerance values
	0FF	Checkweighing feature not active

9.2	Ⓛ.Ⓛ.	Checkweigh Limit Entry
	5Ⓛr	Scroll from recalled value: Use the OVER or UNDER button to recall a limit. Then use the OVER and UNDER buttons to increase or decrease the recalled target value.
	5Ⓛ5	Scroll from reference weight: Place an item on the platform and press the OVER or UNDER button to enter that weight as a target value. The OVER and UNDER buttons can then be used to increase or decrease the value.
	Pb	Reference weight only: Place an item on the platform and press the OVER or UNDER button to enter that weight as a target value.

9.3	0.u.	Zero Band Checkweighing Limits Only applicable when Ⓛ.0 is set to 0A or 05.
	1	+/- 1 division
	2	+/- 2 divisions
	3	+/- 3 divisions
	4	+/- 4 divisions
	5	+/- 5 divisions
	7	+/- 7 divisions
	10	+/- 10 divisions
	15	+/- 15 divisions
	20	+/- 20 divisions
	30	+/- 30 divisions

9.7	out	Output Configuration	
	no	Do not enter Output selection menu	
	YES	Enter menu	
		01-0	Output Configuration
		01 OFF	Output is deactivated
		01 TH5	Weight below threshold level (2.5 TH5) used for output logic
		01 in1	Remote Switch Input Logic 1 used for output logic
		01 in2	Remote Switch Input Logic 2 used for output logic
		01 Lo	Low annunciator used for output logic
		01 udr	Under annunciator used for output logic
		01 Acc	Accept annunciator used for output logic
		01 over	Over annunciator used for output logic
		01 Hi	High annunciator used for output logic

Exit – 99 don

10.1	donE	Exit and save changes
	n	Do not exit
	y	Save changes and exit

Data Communications

To confirm data has been transmitted, the display will show a "r" in the leftmost digit.

Transmit on Demand (t0d)

In this mode, scale data is transmitted whenever PRINT is pressed, a remote switch configured for a PRINT command is pressed, or a print request is received at the serial port. The scale must be stable and the scale value must be valid before transmission.

Timer 1 (t1)

Transmits every 1 second.

Timer 5 (t5)

Transmits every 5 seconds.

Timer 60 (t60)

Transmits every 60 seconds.

Continuous Data Transmission (CP)

Data is transmitted each time the scale display updates. Readings which occur when the scale is in motion are indicated out by the abbreviation "MOT." after the weight data.

Auto Print 1 (AP1)

Auto Print 1 transmits the first stable scale reading each time the scale leaves motion.

Auto Print 2 (AP2)

Auto Print 2 transmits the first stable scale reading following the scale leaving motion and above the adjustable threshold level. To adjust the Threshold level as a % of capacity, see the Threshold Level (2.5 tH5) parameter. In Auto Print 2, no further readings will be sent until the scale returns to weight reading that is below the adjustable threshold level.

Auto Print 3 (AP3)

Auto Print 3 transmits the first stable scale reading following the scale leaving motion, within the ACCEPT band and above the adjustable threshold level. To adjust the Threshold level as a % of capacity, see the Threshold Level (2.5 tH5) parameter. In Auto Print 3, no further readings will be sent until the scale returns to weight reading that is below the adjustable threshold level.

Auto Print 4 (AP4)

Auto Print 4 transmits the first stable scale reading following the scale leaving motion that is above the adjustable threshold level. Transmission does not occur until the scale returns below the threshold value. To adjust the threshold level as a % of capacity, see the Threshold Level (2.5 tH5) parameter.

Auto Print 5 (AP5)

Auto Print 5 transmits the last stable scale reading following the scale leaving motion that is above the adjustable threshold level. Transmission does not occur until the scale

returns below the threshold value. To adjust the threshold level as a % of capacity, see the Threshold Level (2.5 TH5) parameter.

Data String Formatting

Many predefined data formats are available. This allows for flexibility when communicating with a database, printer, remote display or other devices.

The LB1-4 custom data strings provide the opportunity to define a custom print string up to 64 characters in length.

Note: Lb:oz unit is not supported in data strings.

	Print String	Description
F0	<p>Standard Output Format</p> <p><STX><p><xxxx.xx><SP><uu><SP> <MOT><CR><LF></p> <p>Sample Print String ±--10.05-lb</p> <p>Note: "-" represents a space</p>	<p><STX> Start of Text (02h) <p> Weight Polarity Negative weight "-", positive weight space (20h) <xxxx.xx> Weight Data fixed field of 6 digits plus decimal. In overload or underload "-----". Leading zeros are spaces (20h). <uu> Displayed Units "lb", "kg", "oz", "g" <MOT> (Available only in Continuous print mode) Motion Status Appends "MOT" to the print string when printing while in motion <SP> Line Space (20h) <CR> Carriage Return (0dh) <LF> Line Feed (0Ah)</p>
2d	<p>Dual Unit lb and kg Print Output Format</p> <p><STX><p><xxxx.xx><SP><uu><SP> <MOT><CR><LF> <(><p><xxxx.xx><SP><kg><SP><)><MOT><CR><LF></p> <p>Sample Print String ±--10.05-lb ±---4.56-kg</p> <p>Note: "-" represents a space</p>	<p><STX> Start of Text (02h) <p> Weight Polarity Negative weight "-", positive weight space (20h) <xxxx.xx> Weight Data fixed field of 6 digits plus decimal. In overload or underload "-----". Leading zeros are spaces (20h) <uu> Displayed Units "lb", "kg", "oz", "g" <MOT> (Available only in Continuous print mode) Motion Status Appends "MOT" to the print string when printing while in motion <SP> Line Space (20h) <CR> Carriage Return (0dh) <LF> Line Feed (0Ah)</p>

	Print String	Description
55P	<p>Label Printer Output Format</p> <pre><FR"L1"><LF><?><LF><p><xxxx.xx><LF> <uu><LF><"GS"><LF><MOT><LF><p> <xxxx.xx><LF><kg><LF><P1,1><LF></pre> <p>Sample Print String</p> <pre>FR"L1" ? ±--10.05 lb GS MOT ±---4.56 kg P1,1</pre> <p>Note: "-" represents a space</p>	<p><p> Weight Polarity Negative weight "-", positive weight space (20h)</p> <p><xxxx.xx> Weight Data fixed field of 6 digits plus decimal. In overload or underload "-----". Leading zeros are spaces (20h)</p> <p><uu> Displayed Units "lb", "kg", "oz", "g"</p> <p><MOT> (Available only in Continuous print mode) Motion Status Appends "MOT" to the print string when printing while in motion</p> <p><SP> Line Space (20h)</p> <p><CR> Carriage Return (0dh)</p> <p><LF> Line Feed (0Ah)</p>
F9	<p>Prints current weight, units, and "grs".</p> <pre><STX><p><xxxx.xx><SP><uu><SP><grs> ><MOT><CR><LF></pre> <p>Sample Print String</p> <pre>±--10.05-lb-grs</pre> <p>Note: "-" represents a space</p>	<p><STX> Start of Text (02h)</p> <p><p> Weight Polarity Negative weight "-", positive weight space (20h)</p> <p><xxxx.xx> Weight Data fixed field of 6 digits plus decimal. In overload or underload "-----". Leading zeros are spaces (20h)</p> <p><uu> Displayed Units "lb", "kg", "oz", "g"</p> <p><MOT> (Available only in Continuous print mode) Motion Status Appends "MOT" to the print string when printing while in motion</p> <p><SP> Line Space (20h)</p> <p><CR> Carriage Return (0dh)</p> <p><LF> Line Feed (0Ah)</p>

	Print String	Description
lb1	<p>Custom Data String 1 (\x\w \u \m\r\l)</p> <p><STX><p><xxxx.xx><SP><uu><SP> <MOT><CR><LF></p> <p>Sample Print String ±--10.05-lb</p> <p>Note: "-" represents a space</p>	<p><STX> Start of Text (02h)</p> <p><p> Weight Polarity Negative weight "-", positive weight space (20h)</p> <p><xxxx.xx> Weight Data fixed field of 6 digits plus decimal. In overload or underload "-----". Leading zeros are spaces (20h)</p> <p><uu> Displayed Units "lb", "kg", "oz", "g"</p> <p><MOT> (Available only in Continuous print mode) Motion Status Appends "MOT" to the print string when printing while in motion</p> <p><SP> Line Space (20h)</p> <p><CR> Carriage Return (0dh)</p> <p><LF> Line Feed (0Ah)</p>
lb2	<p>Custom Data String 2 (\x\w \u \m\r\l)</p> <p><STX><p><xxxx.xx><SP><uu><SP> <MOT><CR><LF></p> <p>Sample Print String ±--10.05-lb-ACCEPT</p> <p>Note: "-" represents a space</p>	<p><STX> Start of Text (02h)</p> <p><p> Weight Polarity Negative weight "-", positive weight space (20h)</p> <p><xxxx.xx> Weight Data fixed field of 6 digits plus decimal. In overload or underload "-----". Leading zeros are spaces (20h)</p> <p><uu> Displayed Units "lb", "kg", "oz", "g"</p> <p><MOT> (Available only in Continuous print mode) Motion Status Appends "MOT" to the print string when printing while in motion</p> <p><SP> Line Space (20h)</p> <p><CR> Carriage Return (0dh)</p> <p><LF> Line Feed (0Ah)</p>

	Print String	Description
163	<p>Custom Data String 3(\xID:\i \w \u \m\r\l)</p> <p><STX><"ID:"><SP><p><xxxx.xx><SP><u>\u><SP><MOT><CR><LF></p> <p>Sample Print String ID:00-±--10.05-lb</p> <p>Note: "-" represents a space</p>	<p><p> Weight Polarity Negative weight "-", positive weight space (20h) <xxxx.xx> Weight Data fixed field of 6 digits plus decimal. In overload or underload "-----". Leading zeros are spaces (20h) <SP> Line Space (20h) <uu> Displayed Units "lb", "kg", "oz", "g" <MOT> (Available only in Continuous print mode , non-LFT) Motion Status Appends "MOT" to the print string when printing while in motion. <CR> Carriage Return (0dh) <LF> Line Feed (0Ah)</p>
164	<p>Custom Data String 4(\a \u \r\l\c\r\IP1\r\l)</p> <p><accumulator><SP><uu><SP><CR><LF><counter><CR><LF>"P1" <CR><LF></p> <p>Sample Print String +--10.05-lb- ----36 P1</p> <p>Note: "-" represents a space</p>	<p><+/-xxxx.xx > Weight Data fixed field of 6 digits plus decimal. In overload or underload "-----". Leading zeros are spaces (20h) space (20h) <uu> Displayed Units "lb", "kg", "oz", "g" space (20h) <CR> Carriage Return (0dh) <LF> Line Feed (0Ah) <xxxxxx>counter, Leading zeros are spaces (20h) <CR> Carriage Return (0dh) <LF> Line Feed (0Ah) <CR> Carriage Return (0dh) <LF> Line Feed (0Ah)</p>
160	<p>Prints weight with polarity and units</p> <p><p><xxxx.xx><SP><uu><SP><CR><LF></p> <p>Sample Print String ±--10.05-lb</p> <p>Note: "-" represents a space</p>	<p><p> Weight Polarity Negative weight "-", positive weight space (20h) <xxxx.xx> Weight Data fixed field of 6 digits plus decimal. In overload or underload "-----". Leading zeros are spaces (20h). <SP> Line Space (20h) <uu> Displayed Units "lb", "kg", "oz", "g" <CR> Carriage Return (0dh) <LF> Line Feed (0Ah)</p>

Custom Data String Configuration

Command	Length	Description
\A	8	Accumulated weight: 6 digits with leading zeros, polarity, and a decimal point. Positive polarity is represented as "0"
\ax	6-8	Accumulated weight, with weight format "x" (x = 1-5)
\B	0	Clears the Accumulator and Counter
\BS	4	Battery Status. Low: "batt" OK: "BATT"
\C	7	Accumulation counter, 7 digits, leading zeros
\c	7	Accumulation counter, 7 digits, leading spaces
\D10	Up to 40	Product description 1, up to 40 characters. Field length = number of characters entered
\D1F	40	Product description 1, all 40 characters. Trailing spaces added where no entry exists
\D20	Up to 40	Product description 2, up to 40 characters. Field length = number of characters entered
\D2F	40	Product description 2, all 40 characters. Trailing spaces added where no entry exists
\d	1-3	Motion aperture ("0.5", "1", "2", "3", "5", "10")
\e	4	Threshold: 2 digits, decimal, and "%"
\f	5	QC Weigh: Alarm timer, 5 digits
\g	3	QC Weigh: Number of samples, 3 digits
\hxx	1	HEX byte. "xx" can be 00 through FF
\I0	Up to 20	Current Product ID, up to characters. Field length = number of characters entered
\IF	20	Current Product ID, all 20 characters. Trailing spaces added where no entry exists
\J	2	Real time clock date. "01" – "31"
\Jpxxx	2	Real time clock date + xxx days. "01" – "31"
\JJ	3	Julian date, 3 characters
\L	0 or 5	QC Weigh mode. No output or "LATE".
\I	1	Linefeed. ASCII 0x0A
\M	2	Real time clock month. "01" – "12"
\Mpxxx	2	Real time clock month + xxx days. "01" – "12"
\m	0 or 3	Motion status. "MOT" if in motion, no output if stable
\nx	6-8	Current NET weight, with weight format "x" (x = 1-5)
\Ox	4	Output "x" operation (x = 1-8). Setpoint number, colon, 2 digits
\oLx	8-10	Checkweigh LOW value, with weight format "x" (x = 1-5)
\oUx	8-10	Checkweigh UNDER value, with weight format "x" (x = 1-5)
\P0x	Up to 40	Product field "x" (x = 1-8), up to 40 characters characters. Field length = number of characters entered

\PFx	40	Product field “x” (x = 1-8), all 40 characters. Trailing spaces added where no entry exists
\P9	5	Product field 9 (counter). 5 digits with leading zeros
\pOx	8-10	Checkweigh OVER value, with weight format “x” (x = 1-5)
\pHx	8-10	Checkweigh HIGH value, with weight format “x” (x = 1-5)
\qx	6-8	Current GROSS weight, with weight format “x” (x = 1-5)
\R	0	Clears TARE and places scale in the GROSS MODE
\r	1	Carriage return. ASCII 0x0D
\s	6	Checkweigh status. 6 characters with trailing spaces (“LOW ”, “UNDER “, “ACCEPT”, “OVER “, “HIGH “)
\TC	7	12-hour time: HH:MM “AM” or “PM”
\Tc	10	12-hour time with seconds: HH:MM:SS “AM” or “PM”
\TM	5	24-hour time: HH:MM
\Tm	8	24-hour time with seconds: HH:MM:SS
\TP	2	“AM” or “PM”
\ts	3	Current TARE status, “grs” or “net”
\tx	6-8	Current TARE weight, with weight format “x” (x = 1-5)
\U	Up to 20	User ID. “U:” followed by user ID
\u	1-2	Current unit. “lb”, “kg”, “g”, “oz”.
\V	1-3	QC weigh mode sample number. “S:” followed by sample number
\W	2	Current weighing mode. “GS” for GROSS and “NT” for NET
\wx	6-8	Current weight, with weight format “x” (x = 1-5)
\x	1	Start of text character. ASCII 0x02
\Y	2	Real time clock year. “00” – “99”
\Ypxxx	2	Real time clock year + xxx days. “00” – “99”
\Y1	1	Least significant digit of year
\y	1	Current weight polarity. “-“ or a space
\y0	1	Current weight polarity. “-“ or “0”
\Z	0	ZERO command

“x” Weight Formats	
1	8 total characters. Polarity, 6 digits + decimal with leading spaces.
2	8 total characters. Polarity, 6 digits + decimal with leading zeros.
3	7 total characters. No polarity, 6 digits + decimal with leading spaces.
4	7 total characters. No polarity, 6 digits + decimal with leading zeros.
5	6 total characters. No polarity, 6 digits no decimal with leading zeros.

Plain text can be inserted into the data string. No control character or slash is necessary for plain text entry.

To download a custom data string, the string must be prefaced by a command to tell the indicator to expect a custom print string.

ELx<string>↵ Enter (Download) custom data string
RLx↵ Read (Upload) custom data string

x is the label buffer number (1 to 4)

↵ is carriage return or enter key in terminal program

The data string can have up to 62 control characters. For example, the following string is 8 characters in length “\w\u\r\|”. The custom string is terminated and download by pressing the enter. To program this string for Lb1 location in the scale’s memory, send the following string:EL1\u\r\|↵

Once programmed, set the Output Format **FOR** parameter to **Lb1** to activate the print string.

Remote Commands

All serial commands require a carriage return (0x0D) as a terminator. Commands can be entered on any communication option or serial port.

W, w	Weight is transmitted out all enabled ports in the format selected for each port.
Wx, wx	Custom data string Lb1-4 can be requested to transmit out all ports. x = 1, 2, 3 or 4.
P, p	Weight data is sent out serial port 2 only
Px, px	Customer data string Lb1-4 can be requested to transmit out serial port 2 only. x = 1, 2, 3, or 4.
U, u	Causes the scale to switch to the next unit of measure. Same as if the UNITS button is pressed.
Ux, ux	Causes the scale to switch to the unit of measure specified by x. x = 1, 2, 3, or 4 where 1=lb, 2=kg, 3=g, 4=oz.
Z, z	Issues a ZERO command to the scale. Note: Scale will not zero if in motion or if an error is displayed.
T, t	Issues a TARE command to the scale. Note: Scale will not TARE if in motion or if an error is displayed.
G, g	Places the scale into gross weight mode.
N, n	Places the scale into net weight mode. Note: The indicator will not be able to enter the net mode if a tare is not present.
MD	The scale will transmit its model number
RV	The scale will transmit its revision number
ELx<data>	Load the user data string, specified by x (1-4), with the data in <data>. <data> can be up to 64 bytes. The indicator responds with an '*' if the command is successful or '?' if unsuccessful.
RLx	Transmit the User data string stored in the location referenced by x.
SW1	The indicator transmits the current wifi SSID.
SW2	The indicator transmits the current wifi password. Only works if scale is in CAL menu.


SW3	Force the wifi option board to reboot and attempt to reconnect.
SW4<data>	Send an SSID to the indicator. The scale will respond with a '*' if the operation was successful and a '?' if it was unsuccessful.
SW5<data>	Send a wifi password to the scale. The scale will respond with a '*' if the operation was successful and a '?' if it was unsuccessful.
SW6	The scale will transmit its current wifi IP address.
SW7	The scale will transmit the current wifi IP port it is using.
SW8<data>	Enter transmit strength (strength 0-12, input in hexadecimal 0-C)
ipconfig	Returns IP address, subnet, gateway, port, SSID, and wifi password
SWB	Displays the received signal strength (RSSI) of a connected wifi board. Note: Refer to the wifi troubleshooting section for more information.
SWC	Removes the wifi board from RSSI mode and return it to normal communications
^Rxx.yy.	Request parameter setting in the format of calibration/setup menu group xx, sub-menu yy. For example: ^R02.05<0x0D> will cause the scale to transmit its threshold value on the port that this command was received on.
^Exx.yy.	This command will enter data to the scale in calibration/setup menu group xx, menu yy. Scale must be in CAL menu.
^RP	Reports the current product
^EP<data>	Enter product
^RFx	Report remote button function 'x' (x = 1 or 2)
^EFx<data>	Enter remote button function 'x' (x = 1 or 2)
^PX	Delete all products
^PD	Delete one product
^US	Start entry of user IDs
^UD<data>	Data for user IDs

^UE	Exit entry of user IDs
x1	RS232 port 1 is echoed to RS232 port 2
x2	RS232 port 2 input is echoed to RS232 port 2
x3	Ethernet is echoed to port 2
x4	Wireless ethernet is echoed to port 2
x5	Scale displays raw counts
x6	Wired ethernet is echoed to USB
x7	Wireless ethernet is echoed to USB
xc	Clears commands x1-x5
xhbn	Enables ethernet "heartbeat" text. Every 30 seconds of ethernet inactivity, hex value 0xCE is output.
xhbf	Disables ethernet "heartbeat" text.

For a complete protocol, please request this document from Doran Technical Support at tech@doranscales.com.

Internal Relay Option

The Internal Relay Option allows up to four relays to be mounted inside the indicator. Three types of relays are available for use with the Internal Relay Option – 6Vdc Electromechanical and Solid State (AC or DC). Specify style of relay at time of order.



Internal Relay Board

Internal Relay Setup:

A twelve conductor cable provides the relay output connections that exits the meter through a watertight. Leave this cable in place when configuring the outputs and refer to the output cable color code table. The Scale does not provide the AC or DC power to run external devices.

Each relay has a three-position output that provides a Common, Normally Open and Normally Closed terminal. The Normally Closed terminal is only available for use with a mechanical relay. Solid State relays can operate as Normally Closed through software configuration only. The following table shows the color codes and terminal connections for the included cable.


Relay Specifications:

6VDC Mechanical Relay, 10A 250VAC / 30VDC
AC Solid State Relay, 2A 100-240VAC
DC Solid State Relay, 2A 5-48VDC

Internal Relay Output Cable Color Code		
Channel	Terminal	Conductor Color
Relay 1 (OUTPUT 1)	TB201 – NC	Red
	TB201 – COM	White
	TB201 – NO	Green
Relay 2 (OUTPUT 2)	TB202 – NC	Black
	TB202 – COM	Blue
	TB202 – NO	Brown
Relay 3 (OUTPUT 3)	TB203 – NC	Grey
	TB203 – COM	Yellow
	TB203 – NO	Tan
Relay 4 (OUTPUT 4)	TB204 – NC	Purple (Pearl)
	TB204 – COM	Pink
	TB204 – NO	Orange

Step-up Relay Circuit

If the current load to be switched is greater than the maximum current limit of the internal relay, i.e. 10 Amps for mechanical relay or 2 Amps for Solid State Relay, a step-up relay circuit is required in order to switch to the higher current loads.



4-20mA Analog Output Option

Introduction

The 4-20mA Analog Output Option is used to provide an analog output that is proportional to the weight on the scale platform. The option board provides an active power loop for the communications. The 4-20mA analog output option can be used to send weight data to a process indicator, a simple on/off controller or to a programmable logic controller.

Setup

The 4-20mA option is automatically calibrated for an output range of 4mA to 20mA, (i.e. 4mA equals zero weight and 20mA equals the scale's capacity). Attach the output cable from the 4-20mA option board to an appropriate controller or indicator. The white lead is connected to the + input of TB2 and the black lead is connected to the – input of TB2.

Calibrate your process indicator or controller according to the manufacturer's instructions. Remember that the option will output 4mA when the scale reads "zero" and 20mA when the scale reads full capacity.

Operation

There is no effect on scale operation, when the 4-20mA Analog Output option is installed, except for battery units which will see a reduction in battery life of approximately 50%.

Wired Ethernet Option

The Ethernet module is installed inside the indicator enclosure. The NEMA4X sealed RJ-45 Ethernet connector is bulkhead mounted to the rear panel of the indicator.

The Wired Ethernet Option auto senses 10/100Base-T networks. The Wired Ethernet Option is fully compliant with the 10/100Base-T Ethernet network standard, transferring data up to 100Mbps. Once the scale is connected you can collect data, remotely configure, or monitor the scale from any computer on the network.

Specifications

Hardware:

Bulkhead mount NEMA4X sealed RJ-45 connector

Network Interface:

10/100Base-T Ethernet protocol, Data rates up to 100Mbps

Static IP

DHCP

Options:

Washdown Safe RJ-45 Ethernet Connector Field Install Kit

Wireless 802.11b/g Ethernet Option

The Wireless Ethernet Option is fully compliant with the 802.11b/g wireless network standard. Wireless communications are protected by up to a 128-bit security encryption.

Specifications

Hardware: Bulkhead mount 2.4 GHz Dipole Antenna

Network Interface:

802.11b/g Ethernet Protocol
Static IP
DHCP
2.4 GHz Frequency
12dBm Transmitting Power
Receiving Sensitivity
-83dBm(Typ.)

Wireless Security: WEP-128, WPA-PSK (TKIP), WPA2-PSK (AES)

Regulatory Approval: FCC ID: T9J-RN171

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio technician for help

Troubleshooting Wifi

If WIFI is not functioning, try the following procedures:

Confirm IP Configuration

Enter the scale's calibration mode (as detailed on page 24) and navigate to parameter group 6 for WIFI. Press ZERO to enter the group, then use UNITS and PRINT to navigate within this group. Ensure that:

- $d.d.w.w$ is not set to $0FF$
- The ip address is properly set
- The subnet mask is properly set
- The ip gateway is properly set
- The port is properly set

Confirm WIFI connection

Enter the scale's calibration mode (see Scale Parameter Setup) and navigate to parameter group 6 for WIFI. Press ZERO to enter the group, then use UNITS and PRINT to navigate within this group. Navigate to the final parameter " $\overline{L5}$ ". If it reads:

- 8 – The unit is not connected
- 88 – The unit is connecting
- 888 – The unit is connected

If the scale is having trouble connecting, consider repositioning the scale and its antenna to strengthen the connection.

Once the scale is connected to Doran's terminal program Dimension, the exact signal strength can be found using the SWB remote command. See the below table for a guide to this signal strength:

Quality:	Wifi decibel value:
Excellent	Greater than -60dB
Good	-60dB – -75dB
Poor	Less than -75dB

Bluetooth Option

Doran Scale's Bluetooth option is a Class 3, Bluetooth 4.0, configured for SPP. The Bluetooth option does not require any external antenna for communication. Once paired, the Bluetooth module will function as a wireless RS232 serial cable. Each Bluetooth module has an individual 12-digit address i.e. "34:81:F4:13:C8:CE".

Computer Setup

To connect the scale's Bluetooth module with your computer; the computer will need to have a Bluetooth device installed. Some computers may or may not have a Bluetooth option. If there is no existing Bluetooth device, a Bluetooth USB dongle can be used. Follow the instructions included with the Bluetooth dongle software to setup the computer.

Bluetooth USB Dongle

Since Bluetooth software drivers and hardware varies among manufacturers, it is recommended to use the USB Bluetooth dongle available from Doran. Support is not available if the customer is not using the Doran supplied USB dongle.

Pairing Devices (Scale)

The scale's Bluetooth module must be paired with your computer to communicate properly. Turn on the scale with the Bluetooth option installed. Be sure to have the scale near the computer to prevent any interference with communication while configuring the Bluetooth module. Wait 30 seconds after the scale is powered up to allow the scale's Bluetooth module to become available.


Bluetooth Specifications

Feature	Implementation
Bluetooth Transmission:	Class 3
Fully Bluetooth:	Bluetooth SIG QDID: B021961
Range:	Up to 10 meters
Frequency:	2.402 – 2.480 GHz
Transmit Power:	+2dBm (typ.)
Receive Sensitivity:	-90dBm (Classic); -92dBm (LE)
Profile:	SPP Serial Port Profile


Bluetooth Pairing Instructions

The following example connects the scale to a Toshiba Bluetooth Stack running on a Windows PC.


Click New Connection




Click Next




The driver will search for the scale.




Select Dual-SPP and click Next




Click Next once to pair




Right-click Dual-SPP and choose Connect




Click Yes to connect




Right-click Dual-SPP and choose Detail...



The COM number will be displayed




Right-click Dual-SPP and choose Connect



Troubleshooting

If any problem persists, contact Doran Tech Support at tech@doranscales.com

Problem	What to Do or Check
Weight reading will not repeat or does not return to zero when weight is removed	Examine the weighing platform for any interferences. Be sure that nothing is inside the platform, under the load cell or the weigh bridge structure
Scale overloads before reaching full capacity	Make sure all four corner overload stops are properly set, if present. Take the platter off the scale, invert it and place it on the platform. With 1/2 of the scale's capacity in test weights concentrated over a corner of the platform, there should be approximately 1/32" of clearance between the stop and the bottom of the spider. Check all four corners then recalibrate the scale.
Scale will not indicate full capacity or go into overload	Make sure that there is nothing caught in the scale under or around the load cell or spider, which would interfere with their movement. If not, check the overload stops using the above procedure.
Scale will not zero when the ZERO button is pressed	Make sure that the scale is stable ( annunciator is off) when ZERO is pressed. If excessive motion is a problem, then it may be necessary to activate the Zero on Demand or change the Display Filter parameter.
Weight readings don't seem to be correct	Check the scale's accuracy with a test weight. Recalibrate if necessary.
Scale drifts off of zero	Check for air currents and/or vibration around the scale. If that is the cause, it may be necessary to set the AZT parameter to a wider setting to compensate
Scale reading is bouncing	Check for air currents and/or vibration around the scale. If that is the cause, it may be necessary to change the Display Filter parameter.

Scale Messages

Message	Meaning
rEL Pb	ZERO pressed and held past needed period
PASSon	Password enabled
Abort	Invalid value entry or screen timeout
CLrAc	0 Tare value has been entered / Tare has been cleared
Er nno	Calibration error: motion detected
Over Ld	The scale is reading an overload condition
Under Ld	The scale is reading an underload condition
Ldn9 0	“Loading Zero” - the scale is filling the average buffer value and does not yet have a valid weight reading
Loww	Prompt to enter the LOW checkweigh value
undEr	Prompt to enter the UNDER checkweigh value
ouEr	Prompt to enter the OVER checkweigh value
h ,9h	Prompt to enter the HIGH checkweigh value
donE	Calibration completed
SRvEd	Exiting CAL mode or other data entry modes
tArE	Prompt for Tare display and entry
dAtE	Display and prompt to enter RTC date
t imE	Display and prompt to enter RTC time
CLr Ac	“Clear Accumulator” - Can be specifically asked for, or happens when units are changed
Ent Cd	Prompt for code entry to get into CAL mode
Error	Improper value entered or improper action requested
Prd Id	Prompt for Product ID selection

nEUV	New Product ID saved from the front panel
CLr ID	Product ID deleted from the front panel
PF 1 – PF 2	Prompt for entry of Product Fields 1 – 9
Error no USER	Invalid user ID entered in QC Weigh or Production Sentry mode
Out QC	Automatic exit of QC Weigh mode

Default to Factory Settings

To return the setup parameters to factory default, follow these steps.

1. Enter Calibration

Front Panel Access

1. Press and hold ZERO and UNITS simultaneously until the audit counters are displayed.
2. Enter CL is displayed
3. Press ZERO 5 times, so that 5 is displayed,
4. Press UNITS

Internal Calibration Button

The calibration push button is located near the center of the board and labeled CAL. Press this button to enter calibration and setup.

2. Press ZERO to enter the 2 CLF9 parameter group
3. Press UNITS to scroll to menu item dEFt n.
4. Press ZERO to change selection to dEFt Y.
5. Press UNITS to advance. The display will return to dEFt n.
6. Press ZERO to change selection to dEFt Y.
7. Press UNITS to advance.
8. The scale will then show 5RUEd.
9. After the 5RUEd message is displayed, the scale then performs its normal power up routine and enters the Calibration mode. At this time, all the parameters will have been reset to their factory default settings.

Scale Default Settings

When reset to default settings, the CAL menu items, setpoints/outputs, and product ID's are reset. The scale will maintain the calibration settings previously used.

A reference for each CAL menu default value can be found the Scale Parameter Menu Setup, listed in bold.

**Doran Scales, Inc.
883 Enterprise Court
St. Charles, IL 60174**

www.doranscales.com