

# Operation Manual

**TBWS**

**Washdown Bench Scales**

## Contents








1. INTRODUCTION.....	1
2. KEY DESCRIPTIONS.....	1
2.1 Second fuctions of the keys.....	1
3. DISPLAY SYMBOLS.....	2
4. BASIC OPERATION.....	2
4.1 Power On/Off.....	2
4.2 Zero.....	2
4.3 Tare.....	2
4.4 Select Unit and Sampling operation.....	2
5. CHECK WEIGHING.....	3
5.1. Set Limits.....	3
5.2. Set Check Weighing.....	3
6. ACCUMULATION.....	3
6.1. Memory Recall.....	4
6.2. Memory Clear.....	4
6.3. Automatically accumulation.....	4
7. PARTS COUNTING.....	4
8. ANIMAL WEIGHING.....	5
9. KEYBOARD LOCK.....	6
10. SET AUTO POWER OFF.....	6
11. SET BACK LIGHT.....	6
12. SPECIFICATION.....	7
13.DIMENSIONS (INCH/MM).....	7
14.ERROR MESSAGE.....	7
15.RS232 OUT PUT.....	8









## 1. INTRODUCTION

- ✓ The TBWS series Bench scales that amplifies signals from a load cell, converts it to digital data and displays it as a mass value.
- ✓ It is suitable for general weighing or more specialized applications such as check weighing, animal weighing and accumulation applications.
- ✓ It can connect the indicator to a printer or a PC.
- ✓ Large LCD with white LED back light displays


## 2. KEY DESCRIPTIONS

Keys	Description
	Power turn ON/OFF
	Set the Zero Display
	To perform a tare function, Subtracts weights.
	Accumulator key, current values will store to the memory, To send the data to printer or PC
	Shift to Gross / Net Weight.
	Counting
	To change the unit

### 2.1 Second functions of the keys

Function	Keys
To confirm the selected menu	
To change the menu and to increase the active digit	
To move the active digit to right	
To move the active digit to left	
To enter in to the menu	
Escape from the menu to normal operation.	

### 3. DISPLAY SYMBOLS

Display	Description
STABLE	Indicate when the scale get stable
ZERO	Indicate when the scale in Zero
TARE	Indicate when the scale in Tare
NET	Indicate when the scale in Net mode.
GROSS	Indicate when the scale in Gross mode
Kg, Lb, Oz	Indicate when the scale in kg, lb, oz unit
pcs	Indicate when the scale in counting
%	Indicate when the scale in percent
	Indicate when the battery charge is getting low
Hold	Indicate when the scale in Hold mode
Auto	Indicate when the scale in Auto

### 4. BASIC OPERATION


#### 4.1 Power On/Off:

Switch on the balance by pressing on/ off key.


The display is switched on and the test is started and if want to switched off, press again the key.



#### 4.2 Zero

Environmental conditions can lead to the balance exactly zero in spite of the Bench not taking any strain. However, you can set the display of your balance to


zero any time by pressing  key and therefore ensure that the weighing starts at zero.

#### 4.3 Tare

The weight of any container can be tared by pressing  button so that with subsequent weighing the net weight of the object being weighed is always displayed.

- Load weight on the Bench.
- Press  key. Zero is displayed, and tare is subtracted.
- Remove weight on the Bench. Tared weight is displayed. It can set only one tare value. It will be shown with a minus value.
- Press G/N to change between gross weight and net weight.
- To clear the tare value, remove the load and press  key. Zero is displayed, tare weight is cleared.

#### 4.4 Select Unit and Sampling operation

Press  key, it can change unit and sampling operation.

## 5. CHECK WEIGHING














It can set an upper or lower limit when weighing with the limits range.

During the limit controls dividing the unit





will indicate whether a value

upper or lower limits with an alarm sound .

### 5.1. Set Limits


- Press  and  key together, display will be show *SEt H*
- Press  key to select *SEt H* or *SEt L*
- Press  key to confirm, display will show *00000* and will blink the last digit.
- Enter the high limit value by using  and  keys to change the active digits and press  key to increment the value.
- Press  key to confirm, display will show *SEt L*
- Enter the high limit value by using  and  keys to change the active digits and press  key to increment the value.
- Press  key to confirm.
- To escape from the settings press  key.

### 5.2. Set Check Weighing

- Press  and  key together, display will be show *SEt H*
- Press  key to select display *bEEP*.
- Press  key to confirm, display will be shown *nonEorotornG*
- **Check mode nonE**: No beep sound in the limits. Function turned off.
- **Check mode ot** :When the weight is between the limits. OK will shown and beeper will be sounded.
- **Check mode ng** : When the weight is out of the limits, the beeper will be sounded and Ok will shown.

**Note: Check weighing available only when weight more than 20d.**


## 6. ACCUMULATION

The scale can be set to accumulate manually by pressing  key. For settings, see the

parameter *P 1 Coñ » ñodE » Pr 2*

Before operation scale should be stable and return to zero, accumulation available only when weight more than 20d

#### Accumulation Operation

- Place the load on the Bench.
- Press  key, when displayed STABLE indication.
- Display will be show *ACC 1* then will be show the total saved value. These displays will be shown only three seconds.
- Remove the weight from the pan.
- When display get zero and stable then place the second weight.
- It can continue until the memory gets fully or 99 items.

#### **6.1. Memory Recall**

To recall the memory press  key.

Display will be show *ACCX* (X: Total number of accumulation) then will be show the total saved value. These displays will be shown only three seconds.

#### **6.2. Memory Clear**

To clear the memory, press  and  keys together.

Display will be show *ACCD* , all accumulation memory cleared from the memory.


#### **6.3. Automatically accumulation.**


The scale can be set to accumulate automatically. For settings, see the parameter *P 1 Coñ » ñodE » AUto*

#### Automatic Accumulation Operation

- Place the load on the Bench.
- When display gets STABLE indication, display will be show *ACC 1* then will be show the total saved value. These displays will be shown only three seconds.
- Remove the weight from the pan.
- When display get zero and stable then place the second weight.
- It can continue until the memory gets fully or 99 items.


### **7. PARTS COUNTING**


To enter the parts counting, press  key and select until display will be show *P 10*

Press  to change the parts quantity.

Options: *P 10 / P 20 / P 50 / P 100 / P 200*














### Parts Counting Operation

- Place the load on the Bench
- Select the parts quantity as per the option
- Choose from option depending on how many pieces/items are on the scale
- Press  key to confirm, display will be shown ---- then will show the quantity
- Then can add goods on the Bench, display will update the parts quantity automatically

Press  key back to the weighing mode..

## 8. ANIMAL WEIGHING

TBWS can use for vibrate loads weigh. This function can use for animal weighing. For settings, see the parameter *P 3 oth » An*




- 1 Press  key during the self checking.
- 2 Display show PN, in succession press  ,  and  to enter.
- 3 Display will be show **p 0 chk.**
- 4 Press  key until display show **p 3 oth.**
- 5 Press  key to confirm.
- 6 Press  key to select ON/OFF.
- 7 Press  key to confirm.
- 8 Press  key twice to back to normal weighing mode and scale will start self-checking.
- 9 Press  &  key together to enter animal weighing mode ,the HOLD indicator will be on
- 10 Bring the load on the platform, display will be show the reading
- 11 It can add or remove loads also update the weighing values.
- 12 To complete the current weighing, remove the weight from the platform.
- 13 To exit animal mode ,Press  &  key together again
- 14 To disable the animal weighing function, set the parameter *P 3 oth » An » off*



## 9. KEYBOARD LOCK





It can set lock key board, for settings, see the parameter *P 30th» Lock*

When the keys are not using with in 10 minutes, the keys will be lock automatically. After entering into the lock function, when we press the keys display will be show *L-Lock*. Then will come to normal display.

If want to unlock and want to use the keys press and hold  ,  and  keys three seconds. Display will be show *U LCK* Then will come to normal display

## 10. SET AUTO POWER OFF

It can set auto power of the scale, when scale not in use, scale will turn off after the setting time.



- Hold  key three seconds display will show *SEt bL*
- Press  key to change *SEt oF* and press  key to confirm
- Press  key to change the options.

<i>SEt oF</i>	<i>oFF</i>	To set auto off function turn off, for scale always on
	<i>oF 5</i>	Set to turn off five minutes later
	<i>oF 15</i>	Set to turn off fifteen minutes later

- After select the auto off option press  key to confirm and press  key to escape from the settings.

## 11. SET BACK LIGHT

It can set back light when scale in use.

- Hold  key three seconds display will show *SEt bL*
- Press  key to confirm


<i>SEt bL</i>	<i>oN</i>	To set auto option. When start to use back light will be on and when stop the operation back light also will off.
	<i>oN</i>	To set always on. After turn on the power, back light also will be on.
	<i>oFF</i>	To set back light turn off. No back light in the operations

- After selecting the backlight option press  key to confirm and press  key to escape from the settings.

## 12. SPECIFICATION

Model	TBWS-100	TBWS-200	TBWS-500
Capacity	100lb / 50kg / 1600oz	200lb / 100kg / 3200oz	500lb/250kg / 8000oz
Display	2.05inch / 52mm LCD		
Housing	Stainless steel		
Operating Temperature	-10°C - 40°C / 14°F - 104°F		
Resolution	1/5000		
Key Pad	7 Keys		
Power	AC (110V/60Hz)/ Battery (6V/4Ah)		
Calibration	Automatic External		
Interface	RS-232 Output		
Load cell drive Voltage	Max: 5V/150mA		
Load Cells	Up to 4 load cell		
ADC	Sigma Delta		
ADC Update	≤1/10 second		
Stabilization Time	One seconds typical		
Gross Weight	46.3 lb (21.0 kg)		

## 13.DIMENSIONS (INCH/MM)



## 14.ERROR MESSAGE

Error Message	Description	Solution
-----	Maximum load exceeded	Unload or reduce weight
<i>Err 1</i>	Incorrect date	Enter the date by using format "yy:mm:dd"
<i>Err 2</i>	Incorrect time	Enter the time by using format "hh:mm:ss"
<i>Err 4</i>	Zero setting error	Zero setting range exceeded due to switching on.(4%max)

		Make sure Bench empty.
<i>Err 5</i>	Key board error	Check the keys and connecter.
<i>Err 6</i>	A/D value out of range	Make sure Bench empty and check the pan is installed proper. Check the load cell connectors.
<i>Err L</i>	Approval setting error	Check the PCB jumper settings. Must be connect jumper pin to K1 (BW series)
<i>--oL--</i>	Over range	Remove the load. Re calibrate
<i>--Lo--</i>	Underload	Minus weight, check the Bench and restart or calibrate.

### 15.RS232 OUT PUT

The TBWS series of scales can be ordered with a standard RS-232 output. It can be connected to DEP-50 receipt printer & DLP-50 label printer.

#### 15.1 Print Format


The image shows three different printout formats from a scale:

- Label Format:** A rectangular label with the text: "THANK YOU", "Weight: 1.745 lb", and "MAR. 05. 2021 07:42:48".
- Receipt Format #1:** A receipt showing a list of six items with their weights: 1 (1.100 lb), 2 (1.100 lb), 3 (1.105 lb), 4 (1.100 lb), 5 (1.100 lb), and 6 (1.100 lb). It also shows a total weight of 6.605 lb and a count of 6.
- Receipt Format #2:** A receipt showing three separate weighing events. Each event lists Gross, Tare, and Net weights. The final total is 1.106 lb.

#### 15.2 Diagram: Serial interface, RS-232 (9pin D type connector)

Pin 2	RXD	Input	Receiving data
Pin 3	TXD	Output	Transmission data
Pin 5	GND	—	Signal ground

#### 9pin D Connector:



**VISION**TECH  
SHOP [www.visiontechshop.com](http://www.visiontechshop.com)

100 Temple Ave. Hackensack, NJ 07601  
Tel:+ 1-201-679-7793