

CENTURY HANGING SCALE

SET - UP

The scale is shipped ready to use. It was calibrated in the manufacturing facility with certified weights, traceable to the National Institute of Standards and Technology (N.I.S.T.).

1. Unpack the scale.
2. Suspend the scale head from a solid support which will allow the scale to swing freely.
3. Attach the pan to the scale.
4. Re-check the suspension once more. The scale must be free to swing and the pan must be suspended from the scale head in such a way that no part is touching a surrounding object.
5. Adjust zero.

ZERO AND TARE ADJUSTMENT

The zero adjust screw is located at the bottom of the scale head. Rotating the screw clockwise or counter-clockwise with a screwdriver will move the pointer to the right or left.

MAINTENANCE

None normally required.