

Operating Manual

**Weighing Indicator  
WE2107**

# Contents

---

<b>Contents.....</b>	<b>3</b>
<b>Typographical conventions.....</b>	<b>9</b>
<b>Important information .....</b>	<b>10</b>
<b>Safety information.....</b>	<b>11</b>
<b>1   Introduction and appropriate use .....</b>	<b>13</b>
<b>2   Special features.....</b>	<b>14</b>
<b>3   Mechanical construction and scope of supply.....</b>	<b>15</b>
<b>4   Scale commissioning overview .....</b>	<b>17</b>
4.1   NAWI application (with / without limit values) .....	18
4.2   NAWI application (counting scale function).....	19
4.3   Batching and tank weighing applications .....	20
<b>5   Electrical connections .....</b>	<b>21</b>
5.1   Notes .....	21
5.2   Cable entry .....	21
5.3   Cable preparation.....	22
5.4   Load cell connection .....	23
5.5   Process outputs .....	24
5.6   Operating voltage.....	24
5.7   Process inputs / analog output .....	25
5.8   WE2107 - RS232 interfaces .....	26
5.9   WE2107M - RS232 and RS485 serial interfaces (2-wire).....	26
5.10   Comments .....	27

<b>6 Control and display functions.....</b>	<b>28</b>
6.1 Device view.....	28
6.2 Operator controls .....	29
6.3 Display.....	30
<b>7 Basic scale functions.....</b>	<b>31</b>
7.1 Switching on and off.....	32
7.2 Gross/net selection .....	32
7.3 Taring .....	33
7.4 Manual tare function.....	33
7.5 Initial zero setting .....	34
7.6 Error displays.....	34
7.7 Standstill recognition.....	35
7.8 Function keys “F1“/ “F2“.....	35
7.9 External operator controls .....	35
<b>8 Parameter menu .....</b>	<b>36</b>
8.1 Calling the Parameter menu.....	36
8.2 Disabling / enabling menu functions .....	36
8.3 Main menu.....	37
8.4 Navigation in the parameter menu.....	38
8.4.1 Navigation in levels 1 and 2.....	38
8.4.2 Navigation in the third parameter level.....	39
8.5 Full menu structure .....	42
8.5.1 Information sub-menu.....	42
8.5.2 Selecting a print protocol and starting printing.....	43
8.5.3 Limit value switches and dosing/filling parameters .....	44
8.5.4 Filter settings, manual tare value and counting function .....	46
8.5.5 Settings for the COM1/2 communications port .....	47
8.5.6 Print protocol settings, adjusting the real-time clock.....	50

---

8.5.7 Function of digital inputs IN1 and IN2 .....	52
8.5.8 Function of keys F1 and F2 .....	53
8.5.9 Test functions.....	56
8.5.10 Basic scale function, menu access selection and legal-for-trade operation.....	57
8.5.11 Setting and adjusting the scale .....	59
8.5.12 Restoring factory settings .....	62
8.5.13 Switching off the device.....	62
<b>9 Filter selection.....</b>	<b>63</b>
<b>10 Scale adjustment.....</b>	<b>64</b>
10.1 Prerequisites for scale adjustment.....	64
10.2 Maximum capacity adjustment at calibration weight (standard method, CAP = CAL).....	65
10.3 Partial load adjustment with the calibration weight (CAL <> CAP).....	66
10.4 Adjustment without a calibration weight (mV/V adjustment) .....	67
10.5 Multi-range scale.....	69
10.6 Taking gravitational acceleration into account.....	69
<b>11 Linearization.....</b>	<b>71</b>
<b>12 Legal-for-trade applications .....</b>	<b>73</b>
<b>13 Functions of keys F1 and F2 .....</b>	<b>77</b>
<b>14 Counting scale .....</b>	<b>79</b>
<b>15 Print function.....</b>	<b>82</b>
15.1 Activating COM2 for the print function .....	82
15.2 Linking the WE2107 to the printer.....	83
15.3 Print protocol selection .....	84
15.4 Starting printing .....	84
15.5 Different print protocols .....	85
15.6 Formatting the printout .....	86

15.7 Setting the date and time.....	89
15.8 Summation function .....	90
<b>16 Interface for a second display.....</b>	<b>91</b>
16.1 Activating COM2 for the second display .....	91
16.2 Linking the WE2107 to the second display .....	92
16.3 Selecting telegram content.....	93
<b>17 Function of the digital inputs .....</b>	<b>94</b>
17.1 Electrical properties and level assignment.....	96
<b>18 Function of the digital outputs.....</b>	<b>97</b>
<b>19 Limit values .....</b>	<b>98</b>
<b>20 Batching and tank weighing.....</b>	<b>99</b>
20.1 Overview .....	99
20.2 Batching (FILL1, portion weighing) .....	100
20.2.1 Digital inputs/outputs .....	101
20.2.2 Parameters .....	101
20.2.3 Description of the dosing cycle .....	103
20.3 Tank weighing (FILL2).....	105
20.3.1 Digital inputs/outputs .....	106
20.3.2 Parameters .....	106
20.3.3 Description of the dosing cycle (portion weighing).....	108
20.3.4 Description of tank filling.....	109
20.3.5 Description of the emptying function .....	110
20.4 Tank weighing (FILL3).....	111
20.4.1 Digital outputs .....	111
20.4.2 Parameters .....	111
20.4.3 Description of the dosing cycle (portion weighing).....	112
20.4.4 Description of tank filling.....	112
20.4.5 Description of the emptying function .....	112

---

<b>21 Analog output (4 - 20 mA).....</b>	<b>113</b>
<b>22 Alibi and calibration memory .....</b>	<b>113</b>
22.1 Calibration memory .....	114
22.2 Alibi memory .....	115
<b>23 Parameter factory settings .....</b>	<b>115</b>
<b>24 Monitoring functions and error messages.....</b>	<b>117</b>
24.1 Monitoring functions .....	117
24.2 Error messages .....	118
<b>25 Maintenance and cleaning.....</b>	<b>120</b>
<b>26 Mechanical dimensions and mounting information.....</b>	<b>122</b>
26.1 WE2107 dimensions (plastic housing, ABS) .....	122
26.2 WE2107M dimensions (stainless steel front panel).....	123
26.3 Wall mounting (WE2107, plastic housing).....	124
26.4 Mounting on a stand (WE2107 in plastic housing) .....	126
26.5 Using as a desktop device (WE2107 in plastic housing) .....	127
26.6 Panel mounting (WE2107M with stainless-steel front panel).....	127
26.7 Sealing / legal-for-trade capability.....	128
26.8 Notes on the achievable degree of protection .....	128
<b>27 Specifications.....</b>	<b>129</b>
<b>Index .....</b>	<b>133</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : the biggest supplier of cash register and scale manuals on the net